



AST Premium 1000

Service Guide





AST Premium 1000

Service Guide

531-0001444

04/99

Adaptec and SCSI*Select* are registered trademarks of Adaptec, Inc.

Ethernet is a trademark of Xerox Corporation.

Intel, Pentium, and LANDesk Server Manager are registered trademarks of Intel Corporation.

Microsoft, Windows, and Windows NT are registered trademarks of Microsoft Corporation.

Adobe and Adobe Acrobat are registered trademarks of Adobe Systems, Inc.

Symbios and Symbios Logic are registered trademarks of Symbios Logic, Inc.

All other trademarks are owned by their respective owners.

Contents

Preface

What This Guide Contains	v
Who Should Read This Guide	v
Warnings and Cautions	v
Conventions Used in This Guide	v
Documentation	vi

Chapter 1

Working Inside the System

Tools and Supplies Needed	1-1
Safety: Before You Remove the Side Cover	1-1
Warnings and Cautions	1-2
Side and Front Covers	1-2
Removing the Side Cover	1-2
Reattaching the Side Cover	1-4
Removing the Front Cover	1-5
Reattaching the Front Cover	1-5
Expansion Boards	1-6
Installing an Expansion Board	1-6
Removing an Expansion Board	1-8
Diskette Drive	1-9
Removing a 3.5-inch Diskette Drive	1-9
Installing a 3.5-inch Diskette Drive	1-10
Peripheral Devices	1-11
Device Cabling Considerations	1-11
Installing a 5.25-inch Removable-Media Device in a Front Bay	1-12
Removing a 5.25-inch Removable-Media Device from a Front Bay	1-14
Installing a SCSI Device in an Internal Bay	1-15
Removing a SCSI Device from an Internal Bay	1-16
Fans	1-17
Removing a Chassis Fan	1-17
Installing a Chassis Fan	1-18

Chapter 2

Upgrading System Board Components

Tools and Supplies Needed	2-1
Warnings and Cautions	2-1
System Board	2-3
Removing the System Board	2-3
Installing the System Board	2-5
DIMMs	2-6
Installing DIMMs	2-6
Removing DIMMs	2-7
Processors	2-8
Removing and Installing an SECC Cartridge Pentium II Processor	2-9
Installing and Removing an SECC2 Cartridge Pentium II/III Processor	2-14
Removing a Processor	2-19

Replacing the Battery	2-21
Setting System Board Jumpers.....	2-23
Jumper Locations and Functions	2-23
General Procedure for Changing a Jumper Setting.....	2-26
Procedures for Changing Specific Jumper Settings	2-27

Chapter 3

Solving Problems

Resetting the System	3-1
Initial System Startup	3-2
Checklist	3-2
New Application Software.....	3-3
Checklist	3-3
After the System Has Been Running Correctly.....	3-4
Checklist	3-4
More Problem-Solving Procedures	3-5
Preparing for Diagnostic Testing.....	3-5
Running Diagnostics.....	3-5
Monitoring POST	3-5
Verifying Proper Operation of Disk Activity Lights	3-6
Confirming Operating System Load.....	3-6
Specific Problems and Corrective Actions	3-6
Power-on Light Does Not Light	3-7
No Audible Beep Codes.....	3-7
No Characters Appear Onscreen	3-7
Onscreen Characters are Distorted or Incorrect.....	3-8
System Cooling Fans Do Not Rotate Properly	3-8
Diskette Drive Activity Light Does Not Light	3-9
Hard Drive Activity Light Does Not Light	3-9
CD-ROM Drive Activity Light Does Not Light.....	3-10
Network Problems	3-10
Problems with Application Software.....	3-12
PCI Installation Tips.....	3-12
Error and Informational Messages	3-13
Standard BIOS Port 80h Codes during POST	3-13
POST Error Codes and Messages.....	3-16

Chapter 4

Technical Reference

System Board Connectors.....	4-2
System Board Jumper Locations and Functions.....	4-4
Interrupts	4-8
Video Modes.....	4-9

Appendix A

Regulatory Specifications

Declaration of Compliance	A-1
Safety Compliances.....	A-1
Electromagnetic Compatibility (EMC).....	A-2
Electromagnetic Compatibility Notice (USA)	A-2
Electromagnetic Compatibility Notices (International).....	A-3

Appendix B

Safety Guidelines, Warnings, and Cautions

Safety Guidelines and Warnings	B-1
Cautions.....	B-3

Preface

What This Guide Contains

This guide contains information about performing service tasks that require the removal of the server covers. Any such task requires a trained service technician.

Who Should Read This Guide

This guide is written for the person trained to service the server hardware.

Warnings and Cautions

Refer to Appendix B for important safety information before beginning any service task.

Conventions Used in This Guide

The following conventions are used throughout this guide:

- Acronyms are spelled out on first mention with the acronym in parentheses. Example: Small Computer System Interface (SCSI). Thereafter, the acronym is used throughout the guide.
- Operator input appears in **boldface** type.
- Menu selections are indicated by the > symbol. Example: The security screen is displayed by selecting **Advanced Menu>Setup>Security**. The symbol > indicates a sub-menu item.
- Book titles, directory names, file names, and variables appear in *italic* type.
- Numbered lists denote operations that must be performed in a specific order. Bulleted lists do not denote specific order.
- Text prefaced with the word **Note** indicates important information that might be overlooked or ignored.
- Text prefaced with the word **CAUTION** specifies actions that could result in the software's loss of integrity or failure.
- Text prefaced with the word **WARNING** specifies actions or conditions that could lead to serious bodily harm.

Documentation

The *Platform and Documentation CD-ROM* contains all related server documentation. The following guides are included in *.pdf* file format:

Title	Description
<i>Product Guide</i>	Contains information on the server architecture and operation.
<i>Service Guide</i>	Contains information on performing service tasks that require the removal of the server covers.
<i>Site Preparation and Hardware Installation Guide</i>	Contains site preparation and hardware installation instructions for the server.

Working Inside the System

This chapter contains procedures for installing and removing the server covers, expansion boards, removable-media drives, hard disk drives, and fans.

Note: For the locations of the components referenced in this chapter, refer to Figure 1-1 in Chapter 1 of the *Product Guide*.

Tools and Supplies Needed

- Phillips (cross-head) screwdriver (#1 and #2 bit)
- Small flat-bladed screwdriver
- Jumper removal tool or needle-nosed pliers
- Anti-static wrist strap and conductive foam pad (recommended)
- Pen or pencil

Safety: Before You Remove the Side Cover

Before removing the side cover at any time, observe these safety guidelines:

1. Turn off all peripheral devices connected to the system.
2. Turn off the system by pressing the push-button power switch on the front of the server.
3. Unplug the AC power cord from the system or wall outlet.
4. Label and disconnect all peripheral cables and all telecommunication lines connected to I/O connectors or ports on the back of the system.
5. Provide some electrostatic discharge (ESD) protection by wearing an anti-static wrist strap attached to the chassis ground—any unpainted metal surface on the system—when handling components.

Warnings and Cautions

The following warnings and cautions apply throughout this manual to any procedure during which you remove the side and/or front cover(s) of the system.

WARNING: System power on/off: The push-button power switch on the front panel **DOES NOT** turn off the system AC power. To remove power from the system, you must unplug the AC power cord from the system or wall outlet.

WARNING: Hazardous conditions, power supply: Hazardous voltage, current, and energy levels are present inside the power supply. There are no user-serviceable parts inside it; only technically qualified personnel should do any servicing on the power supply.

WARNING: Hazardous conditions, devices, and cables: Hazardous electrical conditions may be present on power, telephone, and communication cables. Turn off the system and disconnect the AC power cord, telecommunications systems, networks, and modems attached to the system before opening it. Otherwise, personal injury or equipment damage can result.

CAUTION: Electrostatic discharge (ESD) and ESD protection: ESD can damage disk drives, boards, and other components. We recommend that you perform all procedures in this chapter only at an ESD-protected workstation. If one is not available, provide some ESD protection by wearing an anti-static wrist strap attached to the chassis ground—any unpainted metal surface on the system—when handling components.

CAUTION: ESD and handling boards: Always handle boards carefully. They can be extremely sensitive to ESD. Hold boards only by their edges. After removing a board from its protective wrapper or from the system, place it component-side UP on a grounded, static-free surface. Use a conductive foam pad if available, but NOT the board wrapper. If you place the system board on a conductive surface, the battery leads may short out. If they do, the battery charge is drained, resulting in a loss of CMOS (Complementary Metal Oxide Semiconductor) data. Do not slide any boards across any surfaces.

Side and Front Covers

Removing the Side Cover


You need to remove the side cover, and, in some cases, the front cover, to reach components inside the system. When facing the front of the server, the side cover is on the left.

To remove the side cover, follow these steps:

1. Observe all safety and ESD precautions at the beginning of this chapter.
2. Turn off all peripheral devices connected to the system.

3. Turn off the system by pressing the push-button power switch on the front panel AND unplugging the AC power cord from the system or wall outlet.
4. Label and disconnect all peripheral cables attached to the I/O panel on the back of the system.
5. If there is a padlock installed on the back of the system, unlock and remove it. Refer to Figure 1-1 for the location of the padlock, if one is installed on the system.
6. Remove and save the retaining screws on the back of the side cover.
7. Using an even pull, slide the cover backward, about an inch, until it stops.
8. Using your left hand, pull the back end of the cover toward you to disengage its bottom row of tabs from the slots in the chassis.
9. Using both hands, lift the cover upward to disengage the top row of tabs from the slots in the top edge of the chassis. Set the cover aside.

Figure 1-1. Removing the Side Cover



Reattaching the Side Cover


CAUTION: When you reattach the side cover, do not damage the electromagnetic interference (EMI) gaskets mounted on the cover. Replace any damaged strips; otherwise, the system may not meet EMI requirements.

To reattach the side cover, follow these steps:

1. Observe all safety and ESD precautions at the beginning of this chapter.
2. Before reattaching the cover, check that you have not left any tools or loose parts inside the system.
3. Check that cables, expansion boards, and other components are properly installed.
4. Position the cover over the chassis so that the top row of tabs aligns with the slots in the top of the chassis. Slide the cover toward the front of the system until the cover tabs firmly engage in the chassis.
5. Attach the cover to the chassis with the retaining screws you removed when you removed the cover, and tighten them firmly (6.0 inch-pounds).
6. To prevent unauthorized access inside the system, insert and lock a padlock through the metal loop protruding through the slot in the back of the side cover. Refer to Figure 1-1 for the location of the padlock loop.
7. Connect all external cables and the AC power cord.

Removing the Front Cover

Figure 1-2. Removing the Front Cover



To remove the front cover, follow these steps:

1. Observe all safety and ESD precautions at the beginning of this chapter.
2. Remove the side cover, referring to “Removing the Side Cover” for instructions.
3. Squeeze the three plastic tabs inside the front cover, and push them through the chassis slots.
4. Pull the left side of the cover out slightly, about 15°, until the cover clears the push-button power switch.
5. Slide the cover to the right until the tabs disengage from the chassis slots. Set the cover aside.

Reattaching the Front Cover

To reattach the front cover, follow these steps:

1. Observe all safety and ESD precautions at the beginning of this chapter.
2. Before reattaching the front cover, check that you have not left any tools or loose parts inside the system.

3. Insert the plastic tabs on the front cover into the slots on the right of the chassis.
4. Squeeze the front panel and chassis together along the left side until the plastic tabs snap into their slots.
5. Reattach the side cover, referring to “Reattaching the Side Cover” for instructions.

Expansion Boards

The system board has two full-length ISA bus connectors. One of the connectors shares a chassis expansion slot with a PCI connector. The ISA features include:

- Bus speed up to 8.33 MHz
- 16-bit memory addressing
- Type A transfers at 5.33 Mbps
- Type B transfers at 8 Mbps
- 8- or 16-bit data transfers
- Plug-and-Play ready

The system board has four full-length PCI connectors. One of the connectors shares a chassis expansion slot with an ISA connector. The PCI features include:

- 33 MHz bus speed
- 32-bit memory addressing
- 5 V and 3.3 V signaling environments
- Burst transfers of up to 133 Mbps
- 8-, 16-, or 32-bit data transfers
- Plug-and-Play ready
- Parity enabled

Installing an Expansion Board

CAUTION: Do not overload the system board: Do not overload the system board by installing expansion boards that draw excessive current.


CAUTION: ESD and handling boards: Always handle boards carefully. They can be extremely sensitive to ESD. Hold boards only by their edges. After removing a board from its protective wrapper or from the system, place it component-side UP on a grounded, static-free surface. Use a conductive foam pad if available, but NOT the board wrapper. If you place the system board on a conductive surface, the battery leads may short out. If they do, the battery charge is drained, resulting in a loss of CMOS data. Do not slide any boards across any surfaces.

To install an expansion board, follow these steps:

1. Observe all safety and ESD precautions at the beginning of this chapter.
2. Remove the side cover, referring to “Removing the Side Cover” for instructions.

3. Remove and save the screw that attaches the expansion-slot cover to the chassis. Refer to Item A in Figure 1-3 for the location of this screw. Remove the expansion-slot cover and retain it for possible future use.

Figure 1-3. Installing an Expansion Board



- A Expansion-slot cover and screw
 B Expansion board; uses the same screw

4. Remove the expansion board you are installing from its protective wrapper. Be careful not to touch the components or gold edge connectors. Place the board component-side UP on an anti-static surface.
5. Set any jumpers and/or switches according to the board manufacturer's instructions.
6. Hold the board by its top edge or upper corners. Align the rounded notch in the board-retaining bracket with the threaded hole in the frame. The bracket fits the space formerly occupied by the slot cover you removed in Step 3. The tapered foot of the board-retaining bracket must fit into the mating slot in the expansion-slot frame. Firmly press the board into the slot on the system board.
7. Use the screw you removed in Step 3 to fasten the board to the chassis. Refer to Item B in Figure 1-3 for the location of this screw. Tighten the screw firmly (6.0 inch-pounds).
8. Attach any cables as necessary.
9. Reattach the side cover, referring to "Reattaching the Side Cover" for instructions.

Note: If you install an ISA board that is not Plug and Play, you must run the SSU to reconfigure the system. Running the SSU is optional for a PCI board. For information on running the SSU, see Chapter 4 of the *Product Guide*.

Removing an Expansion Board

CAUTION: Expansion-slot covers must be installed on all vacant expansion slots. This maintains the electromagnetic emissions characteristics of the system and ensures proper cooling of system components.

To remove an expansion board, follow these steps:

1. Observe all safety and ESD precautions at the beginning of this chapter.
2. Remove the side cover, referring to “Removing the Side Cover” for instructions.
3. Disconnect any cables attached to the board you are removing.
4. Remove and save the screw that attaches the board to the chassis. (Item B in Figure 1-3 shows the location of this screw.)
5. Holding the board by its top edge or upper corners, carefully pull it out. Do not scrape the board against other installed components.
6. Store the removed board in an anti-static protective wrapper.
7. If you are not installing a new board in the same slot, install an expansion-slot cover over the vacant expansion slot. The slot cover must fit into the mating slot in the expansion-slot frame.
8. Use the screw you removed in Step 4 to fasten the slot cover to the chassis. Item A in Figure 1-3 shows the location of this screw. Tighten the screw firmly (6.0 inch-pounds).
9. Reattach the side cover, referring to “Reattaching the Side Cover” for instructions.

Note: If you install an ISA board that is not Plug and Play, you must run the SSU to reconfigure the system. Running the SSU is optional for a PCI board. For information on running the SSU, see Chapter 4 of the *Product Guide*.


Diskette Drive

Removing a 3.5-inch Diskette Drive

To remove a 3.5 inch diskette drive, follow these steps:

1. Observe all safety and ESD precautions at the beginning of this chapter.
2. Remove the side cover, referring to “Removing the Side Cover” for instructions.
3. Disconnect the power and signal cables from the diskette drive. Refer to Figure 1-4 for the location of these cables.
4. Remove the screws that secure the drive bay inside the chassis. Then remove the screw that secures the drive carrier to the drive bay.

Figure 1-4. Removing the Drive Cables and Screw




OM05072

- | | |
|---|---------------|
| A | Power cable |
| B | Signal cable |
| C | Chassis screw |

5. Slide the drive assembly (drive and drive bracket) back toward the power supply to disengage the tabs from the slots in the bottom of the 5.25-inch drive bay.
6. Remove the drive assembly from the chassis, and place it component-side UP on an anti-static surface.
7. Referring to Figure 1-5, remove the screws that hold the drive bracket to the drive, and set the screws and the drive bracket aside.
8. Store the removed drive in an anti-static protective wrapper.
9. Reattach the side cover, referring to “Reattaching the Side Cover” for instructions.

Figure 1-5. Removing the Diskette Drive from the Drive Bracket



Installing a 3.5-inch Diskette Drive

To install a 3.5-inch diskette drive, follow these steps:

1. Observe all safety and ESD precautions at the beginning of this chapter.
2. Remove the side cover, referring to “Removing the Side Cover” for instructions.
3. Remove the diskette drive you are installing from its protective wrapper, and place it component-side UP on an anti-static surface.
4. Set any jumpers and/or switches according to the drive manufacturer’s instructions.
5. Place a drive bracket on the component-side of the drive, and align the four mounting holes. (Reuse the drive bracket you removed earlier, if you are performing this drive installation immediately after performing the previous “Removing a 3.5-inch Diskette Drive” procedure.)
6. Attach the drive bracket to the drive, using four screws of the appropriate size and length. (Reuse the screws you removed earlier, if you are performing this drive installation immediately after performing the previous “Removing a 3.5-inch Diskette Drive” procedure.) Tighten the screws firmly (between 4.0 and 6.0 inch-pounds).
7. Place the drive assembly into the front of the cabinet. Make sure the tabs are aligned. Slide the drive assembly toward the front of the system to engage the drive bracket tabs in the slots. Make sure the front of the drive fits correctly in the front opening of the system. When properly positioned, the drive carrier notches extend slightly into the interior of the 5.25-inch drive bay, and the threaded hole in the carrier aligns with the threaded hole in the frame.

8. Secure the drive assembly to the 5.25-inch bay with a screw of the appropriate size and length. (Reuse the screw you removed earlier, if you are performing this drive installation immediately after performing the previous “Removing a 3.5-inch Diskette Drive” procedure.) Tighten the screw firmly (6.0 inch-pounds).
9. Connect the signal and power cables to the drive. (Figure 1-4 shows the positioning of these cables.) The connectors are keyed for ease in reconnecting them to a drive. The red stripe on the signal cable must face toward the center of the drive.
10. Reattach the side cover, referring to “Reattaching the Side Cover” for instructions.
11. Run the SSU to reconfigure the system. For information on running the SSU, see Chapter 4 of the *Product Guide*.

Peripheral Devices

Device Cabling Considerations

This section summarizes drive cabling requirements and constraints for peripheral devices. The number of devices you can install depends on the following:

- The number supported by the bus
- The number of available bays
- The combination of SCSI and IDE devices

SCSI Requirements

The system can accommodate the following combinations of SCSI devices:

- The front bays can accommodate up to three 5.25-inch, half-height, removable-media devices; these devices may include diskette, tape, or CD-ROM drives.
- The internal bay can accommodate:
 - Up to four 3.5-inch, 1.6-inch high internal devices, or
 - Up to six 3.5-inch, 1-inch high internal devices

Note: The standard cable supplied with the system has connectors for three removable-media devices and four internal devices. Therefore, in order to configure the system with six internal devices, an optional SCSI adapter that supports six devices is required.

All SCSI devices must be un-terminated. Termination is installed at the end of the SCSI cable. We recommend that you install hard drives only in internal bays, which means you should route the SCSI cable so that the last device on the cable is a hard drive in an internal bay.

In general, the SCSI cable must be routed from the connector on the system board to the 5.25-inch SCSI devices in the external bays, and finally to the 3.5-inch SCSI devices in the internal bays.

Installing a 5.25-inch Removable-Media Device in a Front Bay

Three 5.25-inch, half-height front bays provide space for removable-media devices, such as diskette, tape, and CD-ROM drives.


CAUTION: Do not install hard drives in 5.25-inch bays: We recommend that you do NOT install hard drives in the 5.25-inch front bays because the drives cannot be properly cooled in this location. Also, hard drives generate EMI and are therefore more susceptible to ESD damage in this location.

Note: Save the filler panels and EMI shields: System cooling and EMI integrity are preserved when drives are installed in the front bays, or when filler panels and EMI shields cover the empty bays. Therefore, when you install a device, save the filler panel and EMI shield that you remove, so that you can reinstall them in the event you later remove the device and leave the bay empty.

Note: Bus termination when installing SCSI devices: It is important that your cabling and connections meet the SCSI bus specification. Otherwise, the bus may be unreliable and data corruption may occur, or devices may not work at all. The SCSI bus is terminated at the end of the cable.

To install a 5.25-inch removable-media device in a front bay, follow these steps:


1. Observe all safety and ESD precautions at the beginning of this chapter.
2. Remove the side and front covers, referring to “Removing the Side Cover” and “Removing the Front Cover” for instructions. Place the front cover on a flat surface.
3. Referring to Figure 1-6, remove the appropriate filler panel. Retain the filler panel for possible future use.
4. Referring to Figure 1-6, remove the appropriate EMI shield by rotating it until it separates from the cabinet. Retain the EMI shield for possible future use.

Figure 1-6. Removing the Filler Panel and EMI Shield from the Front Cover

- A Filler panel
B EMI shield

5. Remove the bay as described in “Removing a 3.5-inch Diskette Drive.”
6. Remove the device you are installing from its protective wrapper, and place it on an anti-static surface.
7. Set any jumpers and/or switches according to the device manufacturer’s instructions.
8. Specify a SCSI ID for the device, using the configuration jumpers on the device. Each SCSI device must be assigned a unique SCSI ID. (The SCSI controller on the system board is always set to SCSI ID 7.)
9. Install the device in the bay, using four screws of the appropriate size and length.
10. Referring to Figure 1-7, install the bay in the system cabinet.
11. Referring to Figure 1-7, connect a signal cable and a power cable to the device. The connectors are keyed and can be inserted in only one way.
12. Reattach the front and side covers, referring to “Reattaching the Front Cover” and “Reattaching the Side Cover” for instructions.

Figure 1-7. Installing a 5.25-inch Removable-Media Device



- A Removable-media device; diskette, tape, or CD-ROM drive
- B Power cable
- C Typical SCSI signal cable

13. Run the SSU to reconfigure the system. For information on running the SSU, see Chapter 4 of the *Product Guide*.

Note: If you have an expansion host adapter board in your system, you may need to run the SSU to set the hard disk drive options to “Not Installed” and the Onboard IDE option to “Disabled.” For information on running the SSU, see Chapter 4 of the *Product Guide*.

Removing a 5.25-inch Removable-Media Device from a Front Bay

To remove a 5.25-inch removable-media device from a front bay, follow these steps:

1. Observe all safety and ESD precautions at the beginning of this chapter.
2. Remove the side and front covers, referring to “Removing the Side Cover” and “Removing the Front Cover” for instructions.
3. Disconnect the power and signal cables from the device.
4. Remove the device bay from the cabinet.
5. Remove and save the four screws that secure the device to the bay.
6. Reinstall the bay inside the cabinet.

7. If you are not installing a device in the now-vacant bay, install a filler panel and an EMI shield on the front cover of the system to cover the opening of the vacant bay.
8. Store the removed device in an anti-static protective wrapper.
9. Reattach the front and side covers, referring to “Reattaching the Front Cover” and “Reattaching the Side Cover” for instructions.


Installing a SCSI Device in an Internal Bay

Note: If you install a SCSI cable other than the one supplied with the system, you must provide active SCSI bus termination at the end of the cable. Leaving the cable installed without active termination violates the SCSI bus specification and causes the SCSI bus to be unreliable.

Note: Ensure that termination is removed or disabled on all SCSI devices other than the last one on the SCSI bus.

To install a SCSI device in an internal bay, follow these steps:

1. Observe all safety and ESD precautions at the beginning of this chapter. See also the cabling considerations in “Device Cabling Considerations.”
2. Remove the side cover, referring to “Removing the Side Cover” for instructions.
3. Disconnect the SCSI signal cable from the connector on the system board.
4. Disconnect the power and signal cables from all the devices installed in the bay.
5. Remove and save the four screws holding the crossbar and bay to the chassis.
6. Slide the bay upward to disengage its tabs from the chassis.
7. Remove the bay from the system cabinet and place it on an anti-static surface.
8. Remove the device you are installing from its protective wrapper, and place it on an anti-static surface.
9. Set any jumpers and/or switches according to the device manufacturer’s instructions.
10. Specify a SCSI ID for the device, using the configuration jumpers on the device. Each SCSI device must be assigned a unique SCSI ID. (The SCSI controller on the system board is always set to SCSI ID 7.)
11. Install the device in the bay, using screws of the appropriate size and length.
12. Reinstall the bay in the chassis. Insert the tabs on the bay into their slots in the chassis. Slide the bay downward until the tabs interlock with the slots.
13. Referring to Figure 1-8, secure the bay to the chassis with the four screws you removed in Step 5. Tighten the screws firmly (6.0 inch-pounds).

Figure 1-8. Securing the Bay to the Chassis

14. Reattach the signal and power cables to all the devices installed in the bay.
15. Reconnect the SCSI signal cable to the connector on the system board.
16. For proper cooling and airflow, neatly fold and secure any excess signal cable (using a tie wrap or cable clip) so that it does not drape across the system board or expansion boards.
17. Reattach the side cover, referring to “Reattaching the Side Cover” for instructions.
18. This step is optional: Run the *SCSISelect* utility to configure the SCSI devices installed on the system. For information on running the *SCSISelect* utility, see Chapter 5 of the *Product Guide*.

Note: If you have a RAID adapter, you must configure and initialize the new SCSI device by running the RAID utility that matches your adapter. Refer to Chapter 5 of the *Product Guide* for more information on running these RAID utilities.

Removing a SCSI Device from an Internal Bay

To remove a SCSI device from an internal bay, follow these steps:

1. Observe all safety and ESD precautions at the beginning of this chapter.
2. Remove the side cover, referring to “Removing the Side Cover” for instructions.

3. Disconnect the SCSI signal cable from the connector on the system board.
4. Disconnect the power and signal cables from all the devices installed in the bay.
5. Remove and save the four screws holding the crossbar and bay to the chassis.
6. Slide the bay upward to disengage its tabs from the chassis.
7. Remove the bay from the system cabinet and place it on an anti-static surface.
8. Remove the screws that attach the device to the bay.
9. Remove the device from the bay and store it in an anti-static protective wrapper.
10. Reinstall the bay in the system cabinet. Insert the tabs on the bay into their slots in the chassis. Slide the bay downward until the tabs interlock with the slots.
11. Referring to Figure 1-8, secure the bay to the chassis with the four screws you removed in Step 5. Tighten the screws firmly (6.0 inch-pounds).
12. Reattach the signal and power cables to all the devices installed in the bay.
13. Reconnect the SCSI signal cable to the connector on the system board.
14. For proper cooling and airflow, neatly fold and secure any excess signal cable (using a tie wrap or cable clip) so that it does not drape across the system board or expansion boards.
15. Reattach the side cover, referring to “Reattaching the Side Cover” for instructions.

Fans

For cooling and airflow, the system contains one or more removable chassis fans to cool the internal components. The integrated power supply fan provides additional cooling and airflow.

The procedures in this section describe the removal and installation of chassis fans.


Removing a Chassis Fan

To remove a chassis fan, follow these steps:

1. Observe all safety and ESD precautions at the beginning of this chapter.
2. Remove the side and front covers, referring to “Removing the Side Cover” and “Removing the Front Cover” for instructions.
3. Label and disconnect any cables that are connected to the expansion boards.
4. Remove all the expansion boards. As you remove each board, label it with its slot number so that you can reinstall it in the same slot.
5. Disconnect the fan power cable connector from the fan header on the system board.
6. Remove the plastic, snap-on fan housing assembly by firmly pressing inward on the plastic tabs on the assembly until you can pull the front tabs out of the slots in the chassis.

7. Swing the assembly to the left until you can disengage the plastic tabs on the back side of the assembly from the slots in the chassis.

Figure 1-9. Removing the Fan Housing Assembly




8. Remove the assembly from the chassis and place it on a flat surface.
9. Unsnap the fan from the housing by pressing outward on the plastic tabs that hold the fan in place. Remove the fan from the housing and set it aside.
10. Proceed directly to the following “Installing a Chassis Fan” procedure to install a new fan and reinstall all the components you removed during this procedure.

Installing a Chassis Fan

Note: The chassis fan pulls air from in front of the chassis so that it flows across the boards and out the back of the cabinet. Thus, the fan must be oriented for the correct airflow direction. If you place the fan so that the label faces the back of the chassis, this should provide the correct orientation. You can confirm this by checking the following embossed arrows on the side of the fan as you place it in its bracket:

- ➡ Arrow points horizontally toward the back of chassis
- ↑ Arrow points vertically upward

CAUTION: Replace a failed fan with the same type as the one you removed, with a tachometer signal, or an approved fan. For details about the fan connector, see “Fan Interface Connectors” in Chapter 4. For more information on replacing a fan, contact your customer service representative.

Figure 1-10. Installing a Chassis Fan

Note: The following procedure assumes that you have just removed a chassis fan by completing the steps in the previous “Removing a Chassis Fan” procedure.

To install a chassis fan, follow these steps:

1. Position the cable-side of the fan, with the label-side facing the board guides, over the plastic guide posts in the fan housing.
2. Thread the fan power cable through the opening on the side of the housing, as shown in Figure 1-10. Do not pinch the cable as you snap the fan into the housing.
3. Insert the assembly’s inner-edge plastic tabs, the ones near the fan cable, into the slots in the chassis.
4. Carefully swing the assembly to the right, as if closing a door, until the outer-edge tabs on the fan housing snap into the slots in the front of the chassis. To align these tabs correctly, you may need to repeat Step 1.
5. Reconnect the fan power cable connector to the fan header on the system board. (A fan in the bottom of the housing connects to the Fan 1 header; a fan in the top of the housing connects to the Fan 0 header.)
6. Reinstall all the expansion boards, each into the slot from which it was removed.
7. Reconnect any cables to the expansion boards from which they were removed.
8. Reattach the front and side covers, referring to “Reattaching the Front Cover” and “Reattaching the Side Cover” for instructions.

Upgrading System Board Components

This chapter provides procedures for installing and removing the system board, DIMMs, and processors, and the procedure for replacing the battery. It also shows the locations of the system board jumpers, describes their settings, and provides procedures for changing their settings.

Note: For the system board locations of the connectors, slots, and processors referenced in this chapter, refer to Figure 4-1 in Chapter 4.

Tools and Supplies Needed

- Phillips (cross-head) screwdriver (#1 and #2 bit)
- Small flat-bladed screwdriver
- Jumper removal tool or needle-nosed pliers
- Anti-static wrist strap and conductive foam pad (recommended)

Warnings and Cautions

The following warnings and cautions apply throughout this manual to any procedure during which you remove the side and/or front cover(s) of the system.

WARNING: System power on/off: The push-button power switch on the front panel **DOES NOT** turn off the system AC power. To remove power from the system, you must unplug the AC power cord from the system or wall outlet.

WARNING: Hazardous conditions, power supply: Hazardous voltage, current, and energy levels are present inside the power supply. There are no user-serviceable parts inside it; only technically qualified personnel should do any servicing on the power supply.

WARNING: Hazardous conditions, devices, and cables: Hazardous electrical conditions may be present on power, telephone, and communication cables. Turn off the system and disconnect the AC power cord, telecommunications systems, networks, and modems attached to the system before opening it. Otherwise, personal injury or equipment damage can result.

CAUTION: Electrostatic discharge (ESD) and ESD protection: ESD can damage disk drives, boards, and other components. We recommend that you perform all procedures in this chapter only at an ESD-protected workstation. If one is not available, provide some ESD protection by wearing an anti-static wrist strap attached to the chassis ground—any unpainted metal surface on the system—when handling components.

CAUTION: ESD and handling boards: Always handle boards carefully. They can be extremely sensitive to ESD. Hold boards only by their edges. After removing a board from its protective wrapper or from the system, place it component-side UP on a grounded, static-free surface. Use a conductive foam pad if available, but NOT the board wrapper. If you place the system board on a conductive surface, the battery leads may short out. If they do, the battery charge is drained, resulting in a loss of CMOS data. Do not slide any boards across any surfaces.

CAUTION: Installing or removing jumpers: A jumper is a small, plastic-encased conductor that slips over two jumper pins. Newer jumpers have a small tab on top that you can grip with your fingertips or with a pair of fine, needle-nosed pliers. If your jumpers do not have such a tab, take care when using needle-nosed pliers to remove or install a jumper; grip the narrow sides of the jumper with the pliers, never the wide sides. Gripping the wide sides can damage the contacts inside the jumper, causing intermittent problems with the function controlled by that jumper. Take care to gently grip, but not squeeze, with the pliers or other tool that you use to remove a jumper. Otherwise, you may bend or break the stake pins on the board.

System Board

Removing the System Board

CAUTION: The system board can be extremely sensitive to ESD, and always requires careful handling. After removing it from the system, place it component-side UP on a grounded, static-free surface to prevent the battery leads from shorting out. If you place the board on a conductive surface, the battery leads may short out. If they do, the battery charge is drained, resulting in a loss of CMOS data. Do not slide the system board across any surface.


To remove the system board:

1. Observe all safety and ESD precautions at the beginning of this chapter.
2. Remove the side cover, referring to “Removing the Side Cover” in Chapter 1 for instructions.
3. Label and disconnect any cables that are connected to the expansion boards.
4. Remove all the expansion boards. As you remove each board, label it with its slot number so that you can reinstall it in the same slot.
5. Label and disconnect all the internal cables that are connected to the system board.
6. Remove the fan housing assembly, referring to “Removing a Chassis Fan” in Chapter 1 for instructions.
7. Referring to Figure 2-1, remove the system board retaining screws and set them aside.
8. Pull the board toward you slightly, and slide it carefully toward the front of the server cabinet until its I/O connectors clear the rear of the chassis.
9. Remove the system board, and place it component-side UP on a grounded, static-free surface or in an anti-static bag.

CAUTION: If you place the board on a conductive surface, the battery leads may short out. If they do, the battery charge is drained, resulting in a loss of CMOS data.


10. Remove the EMI gasket that covers the I/O connectors on the board, and set it aside.
11. Proceed directly to the following “Installing the System Board” procedure to (1) install a new system board, or reinstall the existing system board (after performing whatever work you need to do while the system board is removed); then (2) reinstall all the components you removed during this procedure

Figure 2-1. Removing the System Board



OM06414

Figure 2-2. System Board Retaining Screws



OM08213

Installing the System Board

Note: The following procedure assumes that you have just removed the system board by completing the steps in the previous procedure, “Removing the System Board.”

To install the system board, follow these steps:

1. Observe all safety and ESD precautions at the beginning of this chapter.
2. Replace the EMI gasket to cover the I/O connectors on the system board.
3. Position the board over the threaded standoffs inside the chassis. Slide it carefully toward the rear of the server cabinet until the I/O connectors protrude through the back panel.
4. Referring to Figure 2-1, insert one retaining screw through one of the mounting holes of the board and into a threaded standoff. Do not tighten the screw until the next step.
5. Insert the remaining screws through the mounting holes of the board and into the threaded standoffs. Make sure the board is properly seated; then tighten all the screws firmly (6.0 in.-lb).
6. Reinstall the fan housing assembly, referring to “Installing a Chassis Fan” in Chapter 1 for instructions.
7. Reconnect all the internal cables to the system board.
8. Reinstall all the expansion boards, each into the slot from which it was removed.
9. Reconnect any cables to the expansion boards from which they were removed.
10. Reattach the side cover, referring to “Reattaching the Side Cover” in Chapter 1 for instructions.
11. Run the SSU to reconfigure the system. For information on running the SSU, see Chapter 4 of the *Product Guide*.

DIMMs


Installing DIMMs

CAUTION: Use extreme care when installing a DIMM. Applying too much pressure can damage the socket. DIMMs are keyed and can be inserted in only one way.

CAUTION: Mixing dissimilar metals may cause later memory failures, resulting in data corruption. Install DIMMs that have gold-plated edge connectors only in gold-plated sockets.

The server supports from 64 MB to 2 GB of memory, using up to four double-banked DIMMs.

Figure 2-3. Installing DIMMs



OM08214

To install DIMMs, follow these steps:

1. Observe all safety and ESD precautions at the beginning of this chapter, and the cautions at the beginning of this section.
2. Remove the side cover, referring to “Removing the Side Cover” in Chapter 1 for instructions.
3. Holding the DIMM only by its edges, remove it from its anti-static package.
4. Referring to Figure 2-3, orient the DIMM so that the two notches in the bottom edge of the DIMM align with the keyed socket.

5. Insert the bottom edge of the DIMM into the socket, and press down firmly on the DIMM until it seats correctly.
6. Gently push the plastic ejector levers on the socket ends to the upright position.
7. Repeat Steps 3–6 to install each DIMM.
8. Reattach the side cover, referring to “Reattaching the Side Cover” in Chapter 1 for instructions.
9. Run the SSU to reconfigure the system after adding Error Correcting Code (ECC) memory. For information on running the SSU, see Chapter 4 of the *Product Guide*.

Note: Make sure you run the SSU and reconfigure the system. Failure to do so may degrade the performance of the server.

Removing DIMMs

CAUTION: Use extreme care when removing a DIMM. Applying too much pressure can damage the socket. Apply only enough pressure on the plastic ejector levers to release the DIMM.

To remove DIMMs, follow these steps:

1. Observe all safety and ESD precautions at the beginning of this chapter, and the caution at the beginning of this section.
2. Remove the side cover, referring to “Removing the Side Cover” in Chapter 1 for instructions.
3. Gently push the plastic ejector levers out and down to eject a DIMM from its socket.
4. Hold the DIMM only by its edges, being careful not to touch its components or gold edge connectors. Carefully lift it away from the socket, and store it in an anti-static package.
5. Repeat Steps 3 and 4 to remove other DIMMs, as necessary.
6. Reattach the side cover, referring to “Reattaching the Side Cover” in Chapter 1 for instructions.
7. Run the SSU to reconfigure the system after removing ECC memory. For information on running the SSU, see Chapter 4 of the *Product Guide*.

Processors

WARNING: If the system has been running, any installed processor and heat sink on the processor board(s) are hot. To avoid the possibility of a burn, be careful when removing or installing system board components that are located near processors.

CAUTION: Processor must be appropriate: You may damage your system if you install a processor that is inappropriate for it. Make sure your system can handle a newer, faster processor (thermal and power considerations). For exact information about processor interchangeability, contact your customer service representative.


CAUTION: Heat sink must be appropriate: Depending on your configuration, the existing processor may have a passive heat sink. If you REPLACE the processor with a faster one, it must have a fan heat sink (a powered fan instead of a passive heat sink). If you ADD a second processor, it must have a fan heat sink. When adding a processor, you must leave the existing processor in the primary connector (closest to the center of the system board).

CAUTION: ESD and handling processors: Reduce the risk of ESD damage to the processor by doing the following: (1) Touch the metal chassis of the system before touching the processor or system board. Keep part of your body in contact with the metal chassis to dissipate the static charge while handling the processor. (2) Avoid moving around unnecessarily.

Removing and Installing an SECC Cartridge Pentium II Processor

Removing a Pentium II Processor

Figure 2-4. Removing a Pentium II Processor



- A Retention module
- B Power wire
- C System board connector

CAUTION: Do not touch or bend the processor's exposed pins. Reduce the risk of ESD damage to the processor by doing the following:


- Touch the metal chassis of the system before touching the processor or system board. Keep part of your body in contact with the metal chassis to dissipate the static charge while handling the processor.
- Avoid moving around unnecessarily.

To remove a processor, follow these steps:

1. Observe all safety and ESD precautions at the beginning of this chapter and those at the beginning of this section.
2. Remove the side cover, referring to “Removing the Side Cover” in Chapter 1 for instructions.
3. Referring to Figure 2-4, disconnect the power wire from the connector on the system board.
4. Press the processor latches toward the center of the processor cartridge to free them from the retention module. Refer to Figure 2-5 for the location of these latches.
5. Lift the processor cartridge upward, and out of the retention module, as indicated in Figure 2-4.
6. Place the processor cartridge in a piece of conductive foam and store it in an anti-static package.
7. Reattach the side cover, referring to “Reattaching the Side Cover” in Chapter 1 for instructions.

Installing a Pentium II Processor

Figure 2-5. Installing a Pentium II Processor



- A Processor latches
- B Processor cartridge
- C Retention module

CAUTION: Processor must be appropriate: You may damage your system if you install a processor that is inappropriate for it. Make sure your system can handle a newer, faster processor (thermal and power considerations). For exact information about processor interchangeability, contact your customer service representative.


CAUTION: Heat sink must be appropriate: Depending on your configuration, the existing processor may have a passive heat sink. If you REPLACE the processor with a faster one, it must have a fan heat sink (a powered fan instead of a passive heat sink). If you ADD a second processor, it must have a fan heat sink. When adding a processor, you must leave the existing processor in the primary connector (closest to the center of the system board).

CAUTION: Reduce the risk of ESD damage to the processor by doing the following:

- Touch the metal chassis of the system before touching the processor or system board. Keep part of your body in contact with the metal chassis of the system to dissipate the static charge while handling the processor.
- Avoid moving around unnecessarily.

To install a processor, follow these steps:

1. Observe all safety and ESD precautions at the beginning of this chapter and those at the beginning of this section.
2. Remove the side cover, referring to “Removing the Side Cover” in Chapter 1 for instructions.
3. If your system has one processor and you are REPLACING it, proceed to Step 6 now.
4. If your system has two processors and you are REPLACING one or both of them, proceed to Step 7 now.
5. If your system has one processor and you are ADDING a second one, remove the termination board from the empty Slot 1 secondary connector, referring to Figure 2-6. Press the tabs on the top of the termination board toward each other to release them from the retention module, as indicated by Item A in Figure 2-6. Lift the termination board up and out of the retention module, as indicated by Item B in Figure 2-6. Place the termination board in a piece of conductive foam and store it in an anti-static package. Then proceed directly to Step 8.

Figure 2-6. Removing the Termination Board from the Slot 1 Secondary Connector

A Pressing the tabs on the top of the termination board

B Lifting the termination board up and out of the retention module

6. If your system has one processor and you are **REPLACING** it, remove the processor cartridge, referring to the previous “Removing a Pentium II Processor” procedure for instructions. Then proceed directly to Step 8.
7. If your system has two processors and you are **REPLACING** one or both of them, remove the appropriate processor cartridge(s), referring to the previous “Removing a Pentium II Processor” procedure for instructions.
8. Remove the new processor cartridge from its anti-static package and place it on a grounded, static-free surface or conductive foam pad.
9. Orient the processor cartridge so that the heat sink faces the center of the system board. Slide the processor cartridge into the retention module, as indicated in Figure 2-5.
10. Ensure that the alignment notch in the processor cartridge fits over the plug in Slot 1. Push down firmly, with even pressure on both sides of the top, until the processor cartridge is seated.
11. To lock in the processor cartridge, push the latches outward until they click into place in the retention module. Refer to Figure 2-7.


CAUTION: The processor latches must be pushed outward until they click into the retention module. The latches must be secured for proper electrical connection of the processor.

12. Attach the small end of the power cable to the fan connector on the processor cartridge; then attach the large end to the three-pin connector on the system board, as indicated in Figure 2-7.

CAUTION: The fan heat sink power cable must plug into the processor fan connector on the system board.

13. Reattach the side cover, referring to “Reattaching the Side Cover” in Chapter 1 for instructions.
14. Run the BIOS Setup Utility and specify the processor speed. For more information, refer to the discussion of the “CPU Speed Setting” option of the “Main Menu” section in Chapter 4 of the *Product Guide*.

Figure 2-7. Locking the Pentium II Processor into Place



- A Retention module
- B Large end of the power cable
- C 3-pin connector on the system board

Installing and Removing an SECC2 Cartridge Pentium II/III Processor


Note: You must install the fansink onto the SECC2 cartridge Pentium II/III processor before you install the processor module into the socket on the processor board.

Installing the Processor Fansink

To install the fansink to the SECC2 Pentium II/III processor module, follow these steps:


1. Remove the thermal tape protector at the back of the fansink.

Figure 2-8. Removing the Thermal Tape Protector




2. Turn the fansink over and lay it on a flat surface (fan side down, pins up).
3. Position the SECC2 cartridge holes over the fansink pins, lining up the pins with the holes in SECC2 cartridge. See the following figures.

Figure 2-9. Matching the Fansink Clips with the Processor Holes



4. Attach the SECC2 cartridge to the fansink by gently pushing the SECC2 cartridge down onto the fansink.
5. Place the two left holes of the holddown clip on the two left protruding fansink pins, observing the “up” orientation on the clip. Slide the clip to the right.
6. Press down on the right side of the clip, aligning the two right holes of the clip with the two right fansink pins. While holding the right side of the clip down, slide the clip to the left to lock it into place. See the following figure.

Figure 2-10. Installing the Clip



Place this side first over pins and slide to the right.


Press down on the clip placing this side over the pins and slide to the left.

Installing the Processor Module on the Processor Board


To install the processor module on the processor board, follow these steps:

1. Place the retention mechanism over the processor socket on the processor board. Secure it with the screws that came with the package.

Figure 2-11. Installing the Retention Mechanism



2. With the processor module golden fingers pointing downward, align the processor to the posts of the retention mechanism then lower it down. See the following figure.

Figure 2-12. Installing the Processor Module

- Note:** The golden fingers of the processor module are slotted such that they only fit in one direction. Ensure that the module grooves matches the ones on the processor socket.
3. Press down the processor module until the golden fingers completely fit into the socket.
 4. Observe that the latches on the sides of the connectors snap into position to lock the processor module into place.
 5. Locate the fan connectors on the system board and connect the fan cables.

Removing a Processor


To remove a processor, follow the procedures in this section.

Removing a Processor from the Processor Board Slot

To remove the processor module from the slot, follow these steps:

1. Detach the fan cables from the connectors on the system board.
2. Unlock the latches that secure that processor module.
3. Firmly hold the processor module and pull it out of the socket.

Figure 2-13. Removing the Processor Module




Removing the SECC2 Processor from Fansink

To remove the processor fansink, follow these steps:

1. Turn the SECC2/Fansink assembly over and lay it on a flat surface (Fan Side down).
2. Press down on the right side of the retention clip and slide right to release the right pins from the right holes. The clip will bow up to release the right pins.
3. Slide the clip to the left to release the left pins, and remove the clip.
4. Gently pull the SECC2 cartridge away from the Fansink.

Figure 2-14. Removing the SECC2 Cartridge from the Fansink



Replacing the Battery

In the absence of power, the lithium battery on the system board powers the real-time clock (RTC) for up to 10 years. When the battery starts to weaken, it loses voltage, and the system settings stored in CMOS RAM of the RTC (for example, the date and time) may become incorrect. Contact your customer service representative or dealer for a list of approved batteries.

WARNING: If the system has been running, any installed processor and its heat sink are hot. To avoid the possibility of a burn, be careful when removing or installing system board components that are located near processors.

The following warning and translations are required by specific certifying agencies to be printed immediately adjacent to the procedure for replacing the battery.

WARNING: There is danger of an explosion if the battery is incorrectly replaced. Replace it only with the same or equivalent type recommended by the equipment manufacturer. Dispose of used batteries according to the manufacturer's instructions.


ADVARSEL!: Lithiumbatteri - Eksplosionsfare ved fejlagtig håndtering. Udskiftning må kun ske med batteri af samme fabrikat og type. Levér det brugte batteri tilbage til leverandøren.

ADVARSEL: Lithiumbatteri - Eksplosjonsfare. Ved utskifting benyttes kun batteri som anbefalt av apparatfabrikanten. Brukt batteri returneres apparatleverandøren.

WARNING: Explosionsfara vid felaktigt batteribyte. Använd samma batterityp eller en ekvivalent typ som rekommenderas av apparattillverkaren. Kassera använt batteri enligt fabrikantens instruktion.

VAROITUS: Paristo voi räjähtää, jos se on virheellisesti asennettu. Vaihda paristo ainoastaan laitevalmistajan suosittelemaan tyyppiin. Hävitä käytetty paristo valmistajan ohjeiden mukaisesti.

Figure 2-15. Replacing the Battery



OM08215

To replace the battery:


1. Observe all safety and ESD precautions at the beginning of this chapter and those at the beginning of this section.
2. Remove the side cover, referring to “Removing the Side Cover” in Chapter 1 for instructions.
3. Insert the tip of a small flat-bladed screwdriver, or equivalent, under the plastic tab on the snap-on plastic retainer and remove it. (Refer to Item A in Figure 2-15.)
4. Gently push down on the screwdriver to lift the battery. (Refer to Item B in Figure 2-15.)
5. Remove the battery from its socket. (Refer to Item C in Figure 2-15.)
6. Dispose of the battery according to the manufacturer’s instructions and local ordinance.
7. Remove the new battery from its package. Being careful to observe the correct polarity, insert the battery into the battery socket.
8. Reinstall the plastic retainer on the battery socket.
9. Reattach the side cover, referring to “Reattaching the Side Cover” in Chapter 1 for instructions.
10. Run the SSU to restore the CMOS configuration data. For information on running the SSU, refer to Chapter 4 of the *Product Guide*.

Setting System Board Jumpers

Jumper Locations and Functions

Figure 2-2 and Figure 2-17 show the locations of the jumpers on the system board. The shaded area on each jumper illustration shows the default jumper placement. The jumper functions are listed in the tables that follow the figures.


Figure 2-16. System Board Jumpers



WARNING: Moving either of the boot block write protect jumpers (J3J1-A, C) may cause significant damage to the server board. Only move these jumpers when directed to by your customer service representative.

Note: +5 V Standby required for WOL: If you want to use the WOL feature, your power supply must provide 0.8 A of +5 V Standby current. If it does not, your server board may not boot. Move the WOL Enable jumper to the Disabled position if your power supply does not provide the required current.

Jumper Block	Pins (default in bold)	What it does at system reset
A. BMC Boot Block Write Enable	21-22, Protect	BMC boot block is write protected.
	22-23, Erase/ Program	BMC boot block is erasable and programmable.
B. BMC Forced Update Mode	5-6, Normal	System boots normally.
	6-7, Program	System tries to update BMC firmware.
C. BIOS Boot Block Write Enable	1-2, Protect	BIOS boot block is write-protected.
	2-3, Erase/ Program	BIOS boot block is erasable and programmable.
D. Recovery Boot	9-10, Normal	System attempts to boot using the BIOS stored in flash memory.
	10-11, Recovery	BIOS attempts a recovery boot, loading BIOS code from a floppy diskette into the flash device. This is typically used when the BIOS code has been corrupted.
E. Password clear	5-6, Protect	Maintains the current system password.
	6-7, Erase	Clears the password.
F. CMOS clear	1-2, Protect	Preserves the contents of NVRAM.
	2-3, Erase	Replaces the contents of NVRAM with the manufacturing default settings.
G. WOL Enable	1-2, Disabled	Disables Wake On LAN. If your power supply does not provide 0.8 A of +5 V Standby current, you must move the WOL Enable jumper to this position.
	2-3, Enabled	Enables Wake On LAN.

Figure 2-17. AT Style Front Panel Connector

Pin	Signal
1	Power button
2	GND
3	NC
4	+5V
5	NC
6	HD LED
7	+5V
8	GND
9	NC
10	Internal Speaker Enable
11	Speaker Out
12	GND

Pin	Signal
13	NC
14	Power LED
15	NC
16	GND
17	Reset Switch
18	GND
19	NMI switch

General Procedure for Changing a Jumper Setting

WARNING: AC power must be removed from the system before changing the system jumpers.

CAUTION: Installing or removing jumpers: A jumper is a small, plastic-encased conductor that slips over two jumper pins. Newer jumpers have a small tab on top that you can grip with your fingertips or with a pair of fine, needle-nosed pliers. If your jumpers do not have such a tab, take care when using needle-nosed pliers to remove or install a jumper; grip the narrow sides of the jumper with the pliers, never the wide sides. Gripping the wide sides can damage the contacts inside the jumper, causing intermittent problems with the function controlled by that jumper. Take care to gently grip, but not squeeze, with the pliers or other tool that you use to remove a jumper. Otherwise, you may bend or break the stake pins on the board.

Note: The following general procedure for changing a jumper setting applies to most jumpers.

Note: Depending on the function of the jumper, you may need to repeat the procedure to move the jumper back to its original setting. You may also need to run the BIOS Setup Utility and/or the SSU to reconfigure the system. Refer to Chapter 4 of the *Product Guide* for information on using Setup and the SSU.

To change a jumper setting, follow these steps:

1. Observe all safety and ESD precautions at the beginning of this chapter and the warning at the beginning of this section.
2. Remove the side cover, referring to “Removing the Side Cover” in Chapter 1 for instructions.
You do not need to remove the system board from the chassis, and you probably do not need to remove any of the expansion boards.
3. Referring to Figure 2-2 and Figure 2-17, locate the configuration jumpers. Most of them are located at the edge of the system board toward the front of the server cabinet.
4. Move the jumper to the pins specified for the desired setting.
5. Reattach the side cover, referring to “Reattaching the Side Cover” in Chapter 1 for instructions.

Procedures for Changing Specific Jumper Settings

WARNING: AC power must be removed from the system before changing the system jumpers.

CAUTION: Installing or removing jumpers: A jumper is a small, plastic-encased conductor that slips over two jumper pins. Newer jumpers have a small tab on top that you can grip with your fingertips or with a pair of fine, needle-nosed pliers. If your jumpers do not have such a tab, take care when using needle-nosed pliers to remove or install a jumper; grip the narrow sides of the jumper with the pliers, never the wide sides. Gripping the wide sides can damage the contacts inside the jumper, causing intermittent problems with the function controlled by that jumper. Take care to gently grip, but not squeeze, with the pliers or other tool that you use to remove a jumper. Otherwise, you may bend or break the stake pins on the board.

This section provides procedures for changing specific jumper settings, and guidelines for when those settings should be changed.

Note: Depending on the function of the jumper, you may need to repeat the procedure to move the jumper back to its original setting. You may also need to run the BIOS Setup Utility and/or the SSU to reconfigure the system. Refer to Chapter 4 of the *Product Guide* for information on using Setup and the SSU.

CMOS Clear Jumper

The jumper at pins 1–3 of Jumper Block J2J1 controls whether the settings stored in CMOS NVRAM are retained during a system reset, or restored to their factory defaults.

To clear the CMOS contents and restore the factory-default settings, follow these steps:

1. Turn off the server, disconnect the AC power cord from the system, and remove the server side cover.
2. Move the CMOS Clear Jumper from pins 1–2 to pins 2–3.
3. Reinstall the server side cover for your safety, and reconnect the AC power cord to the system.
4. Turn on the monitor and server, and wait for POST to complete.

When POST is complete, the message `NVRAM cleared by jumper` appears. At this point, the automatic reprogramming of CMOS to the factory-default settings has occurred.

5. When the `Press <F2> to enter Setup` message appears, press **F2** to run the BIOS Setup Utility.
6. Make any necessary changes in Setup; then press **F10** to save the new Setup configuration and exit Setup.
7. Turn off the server, disconnect the AC power cord from the system, and remove the server side cover again.
8. Move the CMOS Clear Jumper from pins 2–3 back to pins 1–2.
9. Reinstall the side cover and reconnect the AC power cord to the system.
10. Run the BIOS Setup Utility and the SSU to verify the correct settings. Refer to Chapter 4 of the *Product Guide* for information on using Setup and the SSU.

Password Jumper

The jumper at pins 5–7 of Jumper Block J2J1 controls whether the system password is retained or cleared during a system reset. This jumper may need to be moved if the system password is forgotten.

To clear the current password and enter a new one afterwards, follow these steps:

1. Turn off the server, disconnect the AC power cord from the system, and remove the server side cover.
2. Move the Password Jumper from pins 5–6 to pins 6–7.
3. Reinstall the server side cover for your safety, and reconnect the AC power cord to the system.
4. Turn on the monitor and server, and wait for POST to complete.

When POST is complete, the password has been cleared.

5. Turn off the server, disconnect the AC power cord from the system, and remove the server side cover again.
6. Move the Password Jumper from pins 6–7 back to pins 5–6.
7. Reinstall the side cover and reconnect the AC power cord to the system.
8. Run the SSU to specify a new password. Refer to Chapter 4 of the *Product Guide* for information on using the SSU.

Boot Jumper

Note: This section describes the procedure you must follow to restore the system BIOS after it has been corrupted. Typically, this may occur when an attempted BIOS flash update fails, perhaps due to power being interrupted during the update operation.

The jumper at pins 9–11 of Jumper Block J2J1 controls whether the system tries to boot using the BIOS code stored in system flash memory (normal boot), or performs a recovery boot, loading the BIOS code into system flash memory from a BIOS Flash Backup diskette.

To perform a boot recovery operation and restore the system BIOS, follow these steps:

1. Turn off the server, disconnect the AC power cord from the system, and remove the server side cover.
2. Move the Boot Jumper from pins 9–10 to pins 10–11.
3. Reinstall the server side cover for your safety, and reconnect the AC power cord to the system.
4. Insert the BIOS Flash Backup diskette in drive A and turn on the server.

After the system boots, the speaker emits a single beep when the recovery operation begins. The operation takes about three minutes. When the recovery operation is complete, the speaker emits two beeps to indicate successful completion. While the recovery operation is taking place, there is no screen display. Therefore, you must rely on the beep codes for status information. The following table describes these beep codes.

Boot Recovery Beep Codes

Beep Code	Message
1	The recovery operation is beginning.
2	The recovery operation completes successfully.
4	The system cannot boot from the diskette; it may not be bootable.
Continuous series of low beeps	The wrong BIOS recovery files are found on the diskette, or the Boot Jumper is in the wrong position.

- After the recovery operation completes successfully, turn off the server, disconnect the AC power cord from the system, and remove the server side cover again.
- Move the Boot Jumper from pins 10–11 back to pins 9–10.
- Reinstall the side cover, reconnect the AC power cord to the system, and remove the BIOS Flash Backup diskette from drive A.
- Run the BIOS Setup Utility and the SSU to reconfigure the system as necessary. Refer to Chapter 4 of the *Product Guide* for information on using Setup and the SSU.

BIOS Boot Block Jumper

The jumper at pins 1–3 of Jumper Block J3J1 controls whether the BIOS boot block is protected from erasure and reprogramming.

CAUTION: Leave the BIOS Boot Block Jumper at the factory setting. Programming the BIOS boot block incorrectly prevents the system from booting. Only a technically qualified person should perform BIOS boot block programming, which requires a special “Boot Block Update Utility.” Contact your dealer or sales representative for more information.

Wake on LAN (WOL) Jumper

The jumper at pins 1–3 on Jumper Block J7B1 controls whether WOL is enabled. You change this jumper setting to disable WOL if your power supply does not provide .8A of +5V_Standby current.

To disable WOL, follow these steps:

- Turn off the server, disconnect the AC power cord from the system, and remove the server side cover.
- Move the WOL Jumper from pins 1–2 to pins 2–3.
- Reinstall the server side cover and reconnect the AC power cord to the system.
- Run the SSU to reconfigure the system as necessary. Refer to Chapter 4 of the *Product Guide* for information on using the SSU.

Note: To re-enable WOL, perform Steps 1–4 above, but move the WOL Jumper back to pins 1–2 during Step 2.

Solving Problems

This chapter helps you identify and solve problems that might occur while using the system.

Resetting the System

To do this	Press
Clear system memory and reload the operating system	Ctrl + Alt + Del
Halt power to all peripherals, clear system memory, restart POST, and reload the operating system	Push-button power switch

You can also reset the system from within certain software applications.

Initial System Startup

Problems that occur when the system is powered on for the first time are usually caused by incorrect installation or configuration of the hardware. Equipment failure is a less frequent cause.

Checklist

-
- ☐ Are all the cables correctly connected and secured?
 - ☐ Are the processors fully seated in their slots on the system board?
 - ☐ Are all the expansion boards fully seated in their slots on the system board?
 - ☐ Are all the jumper and switch settings on the system board correct?
 - ☐ Are all the jumper and switch settings on expansion boards and peripheral devices correct?
To check these settings, refer to the manufacturer's documentation for the expansion boards and peripheral devices. If applicable, ensure there are no conflicts – for example, two expansion boards sharing the same interrupt.
 - ☐ Are all the DIMMs installed correctly?
 - ☐ Are all the expansion boards and peripheral devices installed correctly?
 - ☐ If the system has a hard disk drive, is it properly configured and formatted?
 - ☐ Are all the device drivers properly installed?
 - ☐ Are the configuration settings in the SSU correct?
Refer to Chapter 4 of the *Product Guide* for information on using the SSU.
 - ☐ Is the operating system properly loaded?
Refer to the operating system documentation for this information.
 - ☐ Did you press the push-button power switch on the front panel to turn the server on?
If so, the power-on light should be lit.
 - ☐ Is the system AC power cord properly connected to the system and plugged into a NEMA 5-15R outlet for 100-120 V~ or a NEMA 6-15R outlet for 200-240 V~?
 - ☐ Is AC power available at the wall outlet?
-

If you answered “yes” to all the items listed above, but the problem still persists, see “More Problem-Solving Procedures” later in this chapter.

New Application Software

Problems that occur when you run new application software are usually related to the software. Faulty equipment is a much less likely cause, especially if other software runs correctly.

Checklist

-
- ☐ Does the system meet the minimum hardware requirements for the software?
Refer to the software documentation for this information.
 - ☐ Is the software an authorized copy? If not, obtain one; unauthorized copies often do not work.
 - ☐ If you are running the software from a diskette, is it a good copy?
 - ☐ If you are running the software from a CD-ROM, is the CD-ROM scratched or dirty?
 - ☐ If you are running the software from a hard disk, is the software correctly installed? During software installation, were all necessary procedures followed and files installed?
 - ☐ Are the correct device drivers installed?
 - ☐ Is the software correctly configured for the system?
 - ☐ Are you using the software correctly?
-

If you answered “yes” to all the items listed above, but the problem still persists, contact the customer service representative of the software vendor.

After the System Has Been Running Correctly

Problems that occur after the system hardware and software have been running correctly often indicate equipment failure. However, many easily correctable situations can also cause such problems. Sometimes the problem stems from changes made to the system, such as hardware or software that has been added or removed.

Checklist

-
- ☐ If you are running the software from a diskette, try using a new copy of the software.
 - ☐ If you are running the software from a CD-ROM, try a different CD-ROM to see if the problem occurs on all disks.
 - ☐ If you are running the software from a hard disk, try running it from a diskette.
If the software runs correctly, there may be a problem with the copy on the hard disk. Reinstall the software on the hard disk, and try running it again. Make sure all necessary files are installed.
 - ☐ If a software application does not run correctly with the "Boot Speed" set to turbo, try setting the speed to deturbo within Setup.
 - ☐ If the problems are intermittent, there may be a loose cable, dirt in the keyboard (if incorrect keyboard input is a symptom), a marginal power supply, or other random component failures.
 - ☐ If you suspect that a transient voltage spike, power outage, or brownout might have occurred, reload the software and try running it again. (Symptoms of voltage spikes include a flickering video display, unexpected system reboots, and a lack of response by the system to user commands.)
-

Note: Random errors in data files: If you are getting random errors in your data files, they may be getting corrupted by voltage spikes on your power line. If you are experiencing any of the above symptoms that might indicate voltage spikes on the power line, you may want to install a surge suppressor between the wall outlet and the system AC power cord.

More Problem-Solving Procedures

This section provides a more detailed approach to problem identification and resolution.

Preparing for Diagnostic Testing

CAUTION: Turn off all devices before disconnecting cables: Before disconnecting any peripheral cables from the system, turn off the system and any external peripheral devices. Failure to do so can cause permanent damage to the system and/or the peripheral devices.

1. Turn off the system and all external peripheral devices. Disconnect all of them from the system, except the keyboard and monitor.
2. Make sure the system AC power cord is plugged into a properly grounded AC outlet.
3. Make sure the monitor and keyboard are correctly connected to the system. Turn on the video monitor. Set its brightness and contrast controls to at least two-thirds of their maximum ranges. Refer to the documentation supplied with your monitor for this information.
4. If the operating system normally loads from the hard disk, make sure there is no diskette in drive A. Otherwise, place a diskette containing the operating system files in drive A.
5. Turn on the system. If the power-on LED does not light, see “Power-on Light Does Not Light” later in this chapter.

Running Diagnostics

A diagnostics package for the system is contained on the *Platform and Documentation CD-ROM* that was supplied with your system. For documentation about the test modules, see the Diagnostic help disks that end with the extension *.hlp*. The files are ASCII text files that you can print to form a manual of all the tests available for this system.

- The *testview.exe* program uses a simple DOS-based menu system to run test program modules from DOS batch files. It is not for Windows or UNIX MP-RAS. You can access it at the command line prompt without having a hard drive installed.
- The *readme.txt* file for diagnostics tells how to install the program.

CAUTION: Read help information for all tests before running them: The diagnostic package contains many optional tests that should be run only by someone with advanced technical knowledge. Inadvertent actions can be damaging, such as running a hard drive write-test on a hard disk. All tests that require external hardware or user intervention, or are destructive, are disabled in the default configuration. Before running such a test, make sure you read and understand the help information for that test.

Monitoring POST

For information on POST operations, refer to Chapter 4 of the *Product Guide* and “POST Error Codes and Messages” later in this chapter.

Verifying Proper Operation of Disk Activity Lights

While POST is determining the system configuration, it tests for the presence of each mass storage device installed on the system. As each device is checked, its activity light should briefly light up.

Check for the following:

-
- | | |
|--------------------------|---|
| <input type="checkbox"/> | Does the diskette drive activity light turn on briefly?
If not, see “Diskette Drive Activity Light Does Not Light” later in this chapter. |
| <input type="checkbox"/> | If a second diskette drive is installed, does its activity light turn on briefly?
If not, see “Diskette Drive Activity Light Does Not Light” later in this chapter. |
| <input type="checkbox"/> | If there is a hard drive or SCSI devices installed on the system, does the hard drive activity light on the front panel turn on briefly?
If not, see “Hard Drive Activity Light Does Not Light” later in this chapter. |
-

Confirming Operating System Load

After the system boots, the operating system prompt or the customary initial screen should appear. The prompt or initial screen varies depending on the operating system installed. If the operating system prompt or initial screen does not appear, see “Initial System Startup” earlier in this chapter.

Specific Problems and Corrective Actions

This section provides possible solutions for the following specific problems:

- Power-on Light Does Not Light
- No Audible Beep Codes
- No Characters Appear Onscreen
- Onscreen Characters are Distorted or Incorrect
- System Cooling Fans Do Not Rotate Properly
- Diskette Drive Activity Light Does Not Light
- Hard Drive Activity Light Does Not Light
- CD-ROM Drive Activity Light Does Not Light
- Network Problems
- Problems with Application Software
- PCI Installation Tips

For each proposed solution, try the items in the order they are listed. If you cannot correct the problem, contact your service representative or authorized dealer for assistance.

Power-on Light Does Not Light

Check the following:

-
- ☐ Are all the power supplies plugged in? Is the power turned on to the power strip or wall outlet? Do you have a blown fuse or circuit breaker?
 - ☐ Is the system operating normally?
If so, the power LED is probably defective or the cable from the front panel to the system board is loose.
 - ☐ Do other problems with the system exist?
If so, check the items listed under "System Cooling Fans Do Not Rotate Properly" later in this chapter.
-

If all the items listed above are correct, and the problem persists, contact your service representative or authorized dealer for assistance.

No Audible Beep Codes

If the system operates normally, but there are no audible beeps, the speaker may be defective. Run the SSU to verify that the speaker is enabled. If the speaker is enabled in the SSU and the speaker jumper is set correctly, but the speaker still does not function, contact your service representative or authorized dealer for assistance. For more information on correctly setting the speaker jumper, see "Internal Speaker Jumper/External Speaker Connector" in Chapter 2.

No Characters Appear Onscreen

Check the following:

-
- ☐ Is the keyboard working? Check to see that the **Num Lock** light is functioning.
 - ☐ Is the monitor plugged in and turned on?
Many monitors power down when inactive, and may require a moment to warm up when activated by keyboard and/or mouse activity.
 - ☐ Are the brightness and contrast controls on the monitor properly adjusted?
 - ☐ Are the monitor switch settings correct?
 - ☐ Is the monitor signal cable properly installed?
 - ☐ Is the onboard video controller enabled?
-

If you are using a video controller other than the onboard controller, check the following:

1. Verify that the video controller board is fully seated in the system board connector (and verify that the monitor is plugged in to the **ACTIVE** video controller).
2. Run the SSU to disable the onboard video controller and specify that an off-board VGA/EGA adapter is installed. Reboot the system for the changes to take effect.
3. If still no characters appear onscreen after you reboot the system, but POST emits a beep code, record the beep code you hear. This information is useful to your service representative. See "Standard BIOS Port 80h Codes" later in this chapter for information on the beep codes issued during POST.

4. If still no character appear onscreen after you reboot the system, and you do not hear a beep code, the monitor or video controller may have failed. You can verify this by trying to use the monitor on another system or by trying to use a different monitor on this system. Contact your service representative or authorized dealer for assistance.

Onscreen Characters are Distorted or Incorrect

Check the following:

-
- ☐ Are the brightness and contrast controls properly adjusted on the monitor?
Refer to the documentation supplied with your monitor for this information.
 - ☐ Are the signal and power cables of the monitor properly installed?
 - ☐ Is the correct monitor/video board installed for your operating system?
Refer to your operating system documentation for this information.
-

If the problem persists, the video monitor may be faulty or it may be the incorrect type. Contact your service representative or authorized dealer for assistance.

System Cooling Fans Do Not Rotate Properly

If the system cooling fans are not operating properly, system components could be damaged.

Check the following:

-
- ☐ Is AC power available at the wall outlet?
 - ☐ Is the system AC power cord properly connected to the system and the wall outlet?
 - ☐ Did you press the push-button power switch?
 - ☐ Is the power-on light lit?
 - ☐ Have any of the fan motors stopped?
Use the server management subsystem to check the fan status.
 - ☐ Are the fan power connectors properly connected to the system board?
 - ☐ Is the cable from the front-panel board connected to the system board?
 - ☐ Are the power supply cables properly connected to the system board?
 - ☐ Are there any shorted wires caused by pinched cables, or by power connector plugs forced into power connector sockets the wrong way?
-

If the switches and connections are correct and AC power is available at the wall outlet, contact your service representative or authorized dealer for assistance.

Diskette Drive Activity Light Does Not Light

Check the following:

-
- ☐ Are the power and signal cables of the diskette drive properly installed?
 - ☐ Are all relevant switches and jumpers on the diskette drive set correctly?
 - ☐ Is the diskette drive properly configured?
 - ☐ Is the activity light always on?
If so, the signal cable may be plugged in incorrectly.
-

If you are using the onboard diskette controller, run the SSU to verify that “Onboard Floppy” is set to “Enabled.” If you are using a different diskette controller, make sure “Onboard Floppy” is set to “Disabled.” For information on using the SSU, see Chapter 4 of the *Product Guide*.

If the problem persists, there may be a problem with the diskette drive, system board, or drive signal cable. Contact your service representative or authorized dealer for assistance.

Hard Drive Activity Light Does Not Light

If you have installed one or more hard disk drives in your system, check the following:

-
- ☐ Are the power and signal cables of the hard drive properly installed?
 - ☐ If your system contains a SCSI adapter expansion board, is it fully seated in the system board connector?
 - ☐ Are all relevant switches and jumpers on the hard drive and adapter board set correctly?
 - ☐ Is the onboard IDE controller enabled? (IDE hard drives only)
 - ☐ Is the hard drive properly configured?
-

If the problem persists, there may be a problem with the drive, expansion controller board, system board, drive signal cable, or LED connector. Contact your service representative or authorized dealer for assistance.

Note: Front panel hard disk LED indicates IDE and SCSI devices: The hard disk drive activity light on the front panel lights when either an IDE hard disk drive, or a SCSI device controlled by the onboard SCSI host controller, is in use. This LED does not display CD-ROM activity.

CD-ROM Drive Activity Light Does Not Light

Check the following:

-
- ☐ Are the power and signal cables to the CD-ROM drive properly installed?
 - ☐ Are all relevant switches and jumpers on the drive set correctly?
 - ☐ Is the CD-ROM drive properly configured?
Note: Front panel hard disk LED indicates SCSI devices. The hard drive activity light on the front panel lights when a SCSI device controlled by the onboard SCSI host controller is in use. This LED does **not** display CD-ROM drive activity.
 - ☐ Is the onboard IDE controller enabled?
 - ☐ Check the following:
 Is the BIOS set to allow the CD-ROM drive to be the first bootable device?
 The CD-ROM drive may not be spinning fast enough to be detected. To fix this problem, you can increase the hard disk pre-delay to nine seconds.
 If you did not receive error messages, run the SSU and verify that the drive is configured with the correct parameters. To run the SSU, see Chapter 4 of the *Product Guide*.
-

If the problem persists, there may be a problem with the CD-ROM drive, expansion controller board, system board, drive signal cable, or LED connector. Contact your service representative or authorized dealer for assistance.

Network Problems

If you have network problems, consult the documentation that came with the network board you purchased for this server.

Check the following:

-
- ☐ Make sure you are using the drivers shipped on the system Configuration Software CD-ROM for the onboard network controller.
 - ☐ Make sure the driver is loaded and the protocols are bound.
 - ☐ Make sure the network cable is securely attached to the connector at the system back panel and that the network controller Link LED is on (visible at back panel). If the cable is attached, but the problem persists, try a different cable.
 - ☐ Make sure the hub port is configured for the same duplex mode as the network controller.
 - ☐ Check with your LAN administrator about the correct networking software that needs to be installed.
 - ☐ If you are directly connecting two servers (no hub), some hubs may also require a crossover cable. Refer to your hub documentation for more information on crossover cables.
 - ☐ Check the network interface controller LEDs that are visible through an opening at the system back panel.
 The meanings of these LEDs are described in the following table.
-

Network Interface Controller (NIC) LEDs

NIC LED Color	Status	Description
Orange	● On	The network controller is operating at 100 Mbps transfer speed.
	○ Off	The network controller is operating at 10 Mbps transfer speed.
Green	● On	Valid link to the LAN. The network controller and hub are receiving power and the cable connection between the controller and hub is good. There is no network traffic.
	* Blinking	Valid link to the LAN. Data is being sent or received.
	○ Off	The controller and hub are not receiving power, the cable connection between the controller and hub is faulty, or there is a driver configuration problem.

Possible Solutions to Specific Network Problems

If...	Then...
The server hangs when the drivers are loaded.	Change the PCI BIOS interrupt settings. Try the "PCI Installation Tips" that follow.
Diagnostics pass, but the connection fails.	<ul style="list-style-type: none"> • Make sure the network cable is securely attached. • Make sure you specify the correct frame type in your <i>net.cfg</i> file.
The Link LED does not light.	<ul style="list-style-type: none"> • Make sure you have loaded the network drivers. • Check all cable connections. • Try another port on the hub. • Make sure you have the correct type of cable between the adapter and the hub. Some hubs require a crossover cable while others require a straight through cable (for more information on crossover cabling, see your hub documentation).
The Activity LED does not light.	<ul style="list-style-type: none"> • Make sure you have loaded the correct network drivers. • Network may be idle. Try accessing a server.
The controller stopped working when an expansion adapter was installed.	<ul style="list-style-type: none"> • Make sure the cable is connected to the port from the onboard network controller. • Make sure your PCI BIOS is current. Try the "PCI Installation Tips" that follow. • Make sure the other adapter supports shared interrupts. Also, make sure your operating system supports shared interrupts; OS/2 does not. • Try reseating the expansion adapter.
The expansion adapter stopped working without apparent cause.	<ul style="list-style-type: none"> • Try reseating the adapter first; then try a different slot if necessary. • The network driver files may be corrupt or deleted. Delete and then reinstall the drivers. • Run the diagnostics.

Problems with Application Software

If you have problems with application software, check the following:

-
- ☐ Verify that the software is properly configured for the system.
Refer to the software installation and operation documentation for instructions on setting up and using the software.
 - ☐ Try a different copy of the software to determine whether the problem exists with the copy you are using.
 - ☐ Make sure all cables are installed correctly.
 - ☐ Verify that the system board jumpers are set correctly.
Refer to Chapter 2 for jumper locations and settings.
 - ☐ If other software runs correctly on the system, contact your vendor about the failing software.
-

If the problem persists, contact the customer service representative of the software vendor for assistance.

PCI Installation Tips

Some common PCI tips are listed below.

-
- ☐ Reserve interrupts (IRQs) and/or memory addresses specifically for ISA adapters. This prevents PCI boards from trying to use the same settings ISA boards are using. Use the SSU to keep track of ISA adapter resources.
 - ☐ Certain drivers may require interrupts that are not shared with other PCI drivers. The SSU can be used to adjust the interrupt numbers for PCI devices. For certain drivers, it may be necessary to alter settings so that interrupts are not shared.
 - ☐ Check PCI interrupt interdependencies among slots and onboard devices.
-

Error and Informational Messages

When you power on the system, POST displays onscreen messages about the system components as it tests them. If POST encounters a problem in the hardware, software, or firmware, it emits a beep code to indicate the error(s). If POST can display an onscreen message, it emits two beeps as the message appears.

Standard BIOS Port 80h Codes during POST

After the video adapter has been successfully initialized, the current POST testing phase is indicated by a 2-digit hex code that is output to I/O location 80h. If a port 80h ISA POST board is installed, the 2-digit code is displayed on a pair of hex display LEDs. The following tables lists the port 80h codes, the beep codes, and the current testing phase.

Standard Port 80h Code	Beep Code	Current Testing Phase
02		Verify Real Mode
04		Get processor type
06		Initialize system hardware
08		Initialize PCIset registers with initial POST values
09		Set in POST flag
0A		Initialize processor registers and CPU microcode
0B		Enable processor cache
0C		Initialize caches to initial POST values
0E		Initialize I/O
0F		Initialize the local bus IDE
10		Initialize Power Management
11		Load alternate registers with initial POST values
12		Restore processor control word during warm boot (only occurs on warm reboot)
16	1-2-2-3	BIOS ROM checksum
17		Turn cache off
18		8254 timer initialization
20	1-3-1-1	Test DRAM refresh
24		Set ES segment register to 4GB
28		Autosize DRAM
29		Post Memory Manager Initialization (PMM)
2A		Clear 512K base RAM
2C	1-3-4-1	RAM failure on address line xxxx
2E	1-3-4-3	RAM failure on data bits xxxx of low byte of memory bus (1st 4 meg)
2F		Initialize L2 cache if enabled in CMOS
33		Post Dispatch manager Initialization
34		Test CMOS
38		Shadow system BIOS ROM
3A		Autosize cache

Standard Port 80h Code	Beep Code	Current Testing Phase
C1	1-3-1-3	Post error manager Initialization
C4		Initialize system flags in CMOS
14		Initialize keyboard controller
1A		8237 DMA controller initialization
1C		Reset Programmable Interrupt Controller
22		Test 8742 Keyboard Controller
32		Read processor bus-clock frequency and compute boot processor speed
67		Initialize and register other CPU via SMM through APIC bus
69		Initialize SMI handler for the processor
F4		Exit SMI handler
3C	2-1-2-3	Configure advanced PCIset registers and reset coprocessor
3D		Load alternate registers with CMOS values
42		Initialize interrupt vectors
46		Check ROM copyright notice
45		Initialize all pre-PnP devices
49		Initialize PCI bus and devices (also read ESCD and allocate resources)
48		Check video configuration against CMOS (VGA or MDA)
4A		Initialize all video adapters in system
4C		Shadow video BIOS ROM
24		Put CPU in big real mode (flat mode memory addressing - up to 4 GB)
59	2-2-3-1	Post display manager initialization (video screen error codes now visible)
22		Reset and test keyboard first try (only warm reset)
52		Reset and test keyboard controller (both warm and cold reset)
54		Set key click if enabled
76		Enable keyboard
58		Test for unexpected interrupts
4E		Display copyright notice
50		Display processor type and speed
5A		Display prompt "Press F2 to enter SETUP"
5B		Disable CPU L1 cache for memory test
5C		Test RAM between 512 and 640k
60		Test extended memory (4Mb to top of memory)
62		Test extended memory address lines
64		Jump to UserPatch1
66		Configure advanced cache registers
68		Enable external and processor caches
6A		Display external cache size
6C		Display shadow message
6E		Display nondisposable segments
70		Display error messages to video
72		Check for configuration errors
74		Test Real Time Clock
7C		Set up hardware interrupt vectors

Standard Port 80h Code	Beep Code	Current Testing Phase
7E		Test coprocessor if present
88		Initialize BIOS Data Area, timeouts for detecting parallel, serial and hdd controller; Clear CMOS shutdown flag
8A		Initialize Extended BIOS Data Area
81		late post core initialization of devices
87		Configure MCD devices
85		Initialize and detect PC compatible PnP ISA devices (serial, parallel etc)
84		Clear interrupts from com port detection
86		Console redirection initialized
83		Configure onboard hard disk controller
89		Enable NMI
8C		Initialize floppy controller
90		Initialize and detect hard disks
8B		Detect and test for Mouse or Auxiliary device on keyboard controller
95		Install CD-ROM for boot
92		Jump to UserPatch2
C5		Initialize GPNV areas of DMI
98	1-2	Search for option ROMs. One long, two short beeps on checksum failure of an option ROM
93		Scan for User flash ROMs
9C		Set up Power Management (not used)
9D		Enable security
9E		Enable hardware interrupts
A0		Set time of day
A2		Check key lock
A4		Initialize typematic rate
C2		Initialize DMI tables
C3		Log post errors with Post error manager and to SEL in BMC; update VID bits and memory presence to BMC display and FRB errors (watchdog timeouts, BIST or CPU failures)
A8		Erase F2 prompt
AA		Scan for F2 key stroke
AC		Initialize EMP port if selected. Remove com2 from BDA if EMP is enabled Enter SETUP
AE		Clear in-POST flag
B0		Turn on secure boot if enabled (secure front panel, blank video, floppy write protect); Check for errors
B2		POST done – prepare to boot Operating System
B4	1	One short beep before boot
B5		Display Quietboot (not used)
BE		Clear screen
B6		Check password (optional)
BC		Clear parity checkers
BD		Display multiboot menu if esc is hit

Standard Port 80h Code	Beep Code	Current Testing Phase
BF		Display system config summary(if enabled in CMOS)
8F		Get total # of hard drives and put in BDA
91		Program IDE hard drives (timing, PIO modes etc)
9F		Save Total # of hard drives (SCSI and ATA) in BDA
99		Check smart hard drive
C7		Prepare to boot to OS, clean up graphics and PMM areas
C0		Try to boot with INT 19 return to video mode 3 disable PMM return to real mode disable gate A20 clears system memory reset stack Invokes Int19
		Error handling Post codes (may occur at anytime during post)
DO		Interrupt handler error
D2		Unknown interrupt error
D4		Pending interrupt error
D6		Initialize option ROM error
D8		Shutdown error
DA		Extended Block Move
DC		Shutdown 10 error

POST Error Codes and Messages

The following table lists the POST error codes and messages that represent various error conditions POST encounters. The exact POST error codes and message strings and error numbers may be different from those listed here.

POST Error Code	Error Message
0162	BIOS unable to apply BIOS update to processor
0164	BIOS does not support current stepping for processor
0200	Failure Fixed Disk
0210	Stuck Key
0211	Keyboard error
0212	Keyboard Controller Failed
0213	Keyboard locked - Unlock key switch
0220	Monitor type does not match CMOS - Run SETUP
0230	System RAM Failed at offset
0231	Shadow RAM Failed at offset
0232	Extended RAM Failed at offset
0250	System battery is dead - Replace and run SETUP

POST Error Code	Error Message
0251	System CMOS checksum bad - Default configuration used
0260	System timer error
0270	Real time clock error
0297	ECC Memory error in base (extended) memory test in Bank xx
02B2	Incorrect Drive A type - run SETUP
02B3	Incorrect Drive B type - run SETUP
02D0	System cache error - Cache disabled
02F5	DMA Test Failed
02F6	Software NMI Failed
0401	Invalid System Configuration Data - run configuration utility
None	System Configuration Data Read Error
0403	Resource Conflict
0404	Resource Conflict
0405	Expansion ROM not initialized
0406	Warning: IRQ not configured
0504	Resource Conflict
0505	Expansion ROM not initialized
0506	Warning: IRQ not configured
0601	Device configuration changed
0602	Configuration error - device disabled
8100	Processor failed BIST
8104	Processor Internal Error (IERR) failure
8106	Processor Thermal Trip failure
8108	Watchdog Timer failed on last boot
810B	Processor failed initialization on last boot
8110	Server Management Interface failed to function
8120	IOP subsystem is not functional
8150	NVRAM Cleared by Jumper
8151	NVRAM Checksum Error, NVRAM cleared
8152	NVRAM Data Invalid, NVRAM cleared

Technical Reference


This chapter describes locations and/or pinouts for the following:

- System Board Connectors
- System Board Jumper Locations and Functions
- Interrupts
- Video Modes

System Board Connectors

This section provides pin information for the connectors on the system board. Figure 4-1 shows their locations.

Figure 4-1. System Board Connector and Component Locations



A	Chassis intrusion switch connector	J	System fan connector (fan2)
B	CPU fan connector (fan4)	K	External IMB connector
C	Processor slot	L	Hard drive LED connector
D	DIMM slots	M	External WOL connector
E	System fan connector (fan3)	N	Diskette drive connector
F	ATX power connector	O	Wide SCSI connector
G	Auxiliary power connector	P	AGP connector
H	IDE connectors	Q	PCI slots
I	System fan connector (fan1)	R	ISA slots

Fan Connector Pinout

Pin	Signal
1	GND
2	+12V
3	Fan Sensor

WOL Connector Pinout

Pin	Signal
1	+5 VSB
2	GND
3	MP_WAKEUP

Hard Drive LED Connector Pinout

Pin	Signal
1	GND
2	DRV_ACT_L
3	DRV_ACT_L
4	GND

IMB Connector Pinout

Pin	Signal
1	LOCAL_I2C_SCL
2	GND
3	LOCAL_I2C_SDA

Chassis Intrusion Connector Pinout


Pin	Signal
1	GND
3	DETECT_L

System Board Jumper Locations and Functions

For the procedures to change jumpers, see Chapter 2.

Figure 4-2 and Figure 4-3 show the locations of the jumpers on the system board. The shaded area on each jumper illustration shows the default jumper placement. The jumper functions are listed in the tables that follow the figures.

Figure 4-2. System Board Jumpers




WARNING: Moving either of the boot block write protect jumpers (J3J1-A, C) may cause significant damage to the server board. Only move these jumpers when directed to by your customer service representative.

Note: +5 V Standby required for WOL: If you want to use the WOL feature, your power supply must provide 0.8 A of +5 V Standby current. If it does not, your server board may not boot. Move the WOL Enable jumper to the Disabled position if your power supply does not provide the required current.

Jumper Block	Pins (default in bold)	What it does at system reset
A. BMC Boot Block Write Enable	21-22, Protect	BMC boot block is write protected.
	22-23, Erase/ Program	BMC boot block is erasable and programmable.
B. BMC Forced Update Mode	5-6, Normal	System boots normally.
	6-7, Program	System tries to update BMC firmware.
C. BIOS Boot Block Write Enable	1-2, Protect	BIOS boot block is write-protected.
	2-3, Erase/ Program	BIOS boot block is erasable and programmable.
D. Recovery Boot	9-10, Normal	System attempts to boot using the BIOS stored in flash memory.
	10-11, Recovery	BIOS attempts a recovery boot, loading BIOS code from a floppy diskette into the flash device. This is typically used when the BIOS code has been corrupted.
E. Password clear	5-6, Protect	Maintains the current system password.
	6-7, Erase	Clears the password.
F. CMOS clear	1-2, Protect	Preserves the contents of NVRAM.
	2-3, Erase	Replaces the contents of NVRAM with the manufacturing default settings.
G. WOL Enable	1-2, Disabled	Disables Wake On LAN. If your power supply does not provide 0.8 A of +5 V Standby current, you must move the WOL Enable jumper to this position.
	2-3, Enabled	Enables Wake On LAN.

Figure 4-3. AT Style Front Panel Connector



Pin	Signal
1	Power button
2	GND
3	NC
4	+5V
5	NC
6	HD LED
7	+5V
8	GND
9	NC
10	Internal Speaker Enable
11	Speaker Out
12	GND
13	NC
14	Power LED
15	NC
16	GND
17	Reset Switch
18	GND
19	NMI switch

Interrupts

The following table recommends the logical interrupt mapping of interrupt sources. It reflects a typical configuration. Use the information to determine how to program each interrupt. The actual interrupt map is defined using configuration registers in the PIIX4 and the I/O controller.

Note: To disable either IDE controller and reuse the interrupt: If you plan to disable either IDE controller to reuse the interrupt for that controller, you must physically unplug the IDE cable from the board connector (IDE0 or IDE1) if a cable is present. Simply disabling the drive by configuring the SSU option does not free up the interrupt.

Interrupt	Description
INTR	Processor interrupt
NMI	NMI from BUD to processor
IRQ0	Timer interrupt from PIIX4
IRQ1	Keyboard interrupt
IRQ2	Interrupt signal from second 8259 in PIIX4
IRQ3	Serial port A or B interrupt from 87309VLJ device (user can configure)
IRQ4	Serial port A or B interrupt from 87309VLJ device (user can configure)
IRQ5	Open for use
IRQ6	Diskette
IRQ7	Parallel port
IRQ8_L	RTC interrupt
IRQ9	Reserved for SCI (ACPI)
IRQ10	Open for use
IRQ11	Open for use
IRQ12	Mouse interrupt
IRQ14	Compatibility IDE interrupt from primary channel IDE devices 0 and 1
IRQ15	Secondary IDE interrupt
PCI_INTA_L	PCI Interrupt signal A
PCI_INTB_L	PCI Interrupt signal B
PCI_INTC_L	PCI Interrupt signal C
PCI_INTD_L	PCI Interrupt signal D

Video Modes

The 5480 integrated video controller provides all standard IBM VGA modes. With 2 MB of video memory, the system goes beyond standard VGA support. The following tables show all supported video modes using 2 MB of video memory. The following tables show the standard modes that the chip supports, including the number of colors and palette size, resolution, pixel frequency, and scan frequencies.

Standard VGA Modes

Mode(s) in Hex	Bits per pixel	Colors (no per palette size)	Resolution	Pixel Freq. (MHz)	Horizontal Freq. (kHz)	Vertical Freq. (Hz)
0, 1	4	16/256K	360 X 400	14	31.5	70
2, 3	4	16/256K	720 X 400	28	31.5	70
4, 5	4	4/256K	320 X 200	12.5	31.5	70
6	4	2/256K	640 X 200	25	31.5	70
7	4	Mono	720 X 400	28	31.5	70
D	4	16/256K	320 X 200	12.5	31.5	70
E	4	16/256K	640 X 200	25	31.5	70
F	4	Mono	640 X 350	25	31.5	70
10	4	16/256K	640 X 350	25	31.5	70
11	4	2/256K	640 X 480	25	31.5	60
12	4	16/256K	640 X 480	25	31.5	60
12+	4	16/256K	640 X 480	31.5	37.5	75
13	8	256/256K	320 X 200	12.5	31.5	70

Extended VGA Modes

Mode(s) in Hex	Bits per pixel	Colors	Resolution	Pixel Freq. (MHz)	Horiz. Freq. (kHz)	Vert. Freq. (Hz)
58, 6A	8	16/256K	800 X 600	36	35.2	56
58, 6A	8	16/256K	800 X 600	40	37.8	60
58, 6A	8	16/256K	800 X 600	50	48.1	72
58, 6A	8	16/256K	800 X 600	49.5	46.9	75
5C	8	256/256K	800 X 600	36	35.2	56
5C	8	256/256K	800 X 600	40	37.9	60
5C	8	256/256K	800 X 600	50	48.1	72
5C	8	256/256K	800 X 600	49.5	46.9	75
5C	8	256/256K	800 X 600	56.25	53.7	85
5C	8	256/256K	800 X 600	68.2	63.6	100
5D	8	16/256K (interlaced)	1024 X 768	44.9	35.5	43
5D	8	16/256K	1024 X 768	65	48.3	60
5D	8	16/256K	1024 X 768	75	56	70

Mode(s) in Hex	Bits per pixel	Colors	Resolution	Pixel Freq. (MHz)	Horiz. Freq. (kHz)	Vert. Freq. (Hz)
5D	8	16/256K	1024 X 768	78.7	60	75
5E	8	256/256K	640 X 400	25	31.5	70
5F	8	256/256K	640 X 480	25	31.5	60
5F	8	256/256K	640 X 480	31.5	37.9	72
5F	8	256/256K	640 X 480	31.5	37.5	75
5F	8	256/256K	640 X 480	36	43.3	85
5F	8	256/256K	640 X 480	43.2	50.9	100
60	8	256/256K (interlaced)	1024 X 768	44.9	35.5	43
60	8	256/256K	1024 X 768	65	48.3	60
60	8	256/256K	1024 X 768	75	56	70
60	8	256/256K	1024 X 768	78.7	60	75
60	8	256/256K	1024 X 768	94.5	68.3	85
60	8	256/256K	1024 X 768	113.3	81.4	100
64	16	64K	640 X 480	25	31.5	60
64	16	64K	640 X 480	31.5	37.9	72
64	16	64K	640 X 480	31.5	37.5	75
64	16	64K	640 X 480	36	43.3	85
64	16	64K	640 X 480	43.2	50.9	100
65	16	64K	800 X 600	36	35.2	56
65	16	64K	800 X 600	40	37.8	60
65	16	64K	800 X 600	50	48.1	72
65	16	64K	800 X 600	49.5	46.9	75
65	16	64K	800 X 600	56.25	53.7	85
65	16	64K	800 X 600	68.2	63.6	100
66	16	32K	640 X 480	25	31.5	60
66	16	32K	640 X 480	31.5	37.9	72
66	16	32K	640 X 480	31.5	37.5	75
66	16	32K	640 X 480	36	43.3	85
66	16	32K	640 X 480	43.2	50.9	100
67	16	32K	800 X 600	36	35.2	56
67	16	32K	800 X 600	40	37.8	60
67	16	32K	800 X 600	50	48.1	72
67	16	32K	800 X 600	49.5	46.9	75
67	16	32K	800 X 600	56.25	53.7	85
67	16	32K	800 X 600	68.2	63.6	100
68	16	32K (interlaced)	1024 X 768	44.9	35.5	43

Mode(s) in Hex	Bits per pixel	Colors	Resolution	Pixel Freq. (MHz)	Horiz. Freq. (kHz)	Vert. Freq. (Hz)
68	16	32K	1024 X 768	65	48.3	60
68	16	32K	1024 X 768	75	56	70
68	16	32K	1024 X 768	78.7	60	75
68	16	32K	1024 X 768	94.5	68.3	85
68	16	32K	1024 X 768	113.3	81.4	100
6C	8	16/256K (interlaced)	1280 X 1024	75	48	43
6D	8	256/256K (interlaced)	1280 X 1024	75	48	43
6D	8	256/256K	1280 X 1024	108	65	60
6D	8	256/256K	1280 X 1024	135	80	75
6D	8	256/256K	1280 X 1024	157.5	91	85
6E	16	32K	1152 X 864	94.5	63.9	70
6E	16	32K	1152 X 864	108	67.5	75
6E	16	32K	1152 X 864	121.5	76.7	85
6E	16	32K	1152 X 864	143.5	91.5	100
71	24	16M	640 X 480	25	31.5	60
71	24	16M	640 X 480	31.5	37.9	72
71	24	16M	640 X 480	31.5	37.5	75
71	24	16M	640 X 480	36	43.3	85
71	24	16M	640 X 480	43.2	50.9	100
74	16	64K (interlaced)	1024 X 768	44.9	35.5	43
74	16	64K	1024 X 768	65	48.3	60
74	16	64K	1024 X 768	75	56	70
74	16	64K	1024 X 768	78.7	60	75
74	16	64K	1024 X 768	94.5	68.3	85
74	16	64K	1024 X 768	113.3	81.4	100
78	16	32K	800 X 600	36	35.2	56
78	24	16M	800 X 600	40	37.8	60
78	24	16M	800 X 600	50	48.1	72
78	24	16M	800 X 600	49.5	46.9	75
78	24	16M	800 X 600	56.25	53.7	85
78	24	16M	800 X 600	68.2	63.6	100
7B	8	256/256K (interlaced)	1600 X 1200	135	62.5	48
7B	8	256/256K	1600 X 1200	162	75	60

Mode(s) in Hex	Bits per pixel	Colors	Resolution	Pixel Freq. (MHz)	Horiz. Freq. (kHz)	Vert. Freq. (Hz)
7C	8	256/256K	1152 X 864	94.5	63.9	70
7C	8	256/256K	1152 X 864	108	67.5	75
7C	8	256/256K	1152 X 864	121.5	76.7	85
7C	8	256/256K	1152 X 864	143.5	91.5	100
7D	16	64K	1152 X 864	94.5	63.9	70
7D	16	64K	1152 X 864	108	67.5	75
7D	16	64K	1152 X 864	121.5	76.7	85
7D	16	64K	1152 X 864	143.5	91.5	100

Regulatory Specifications

This appendix contains the following:

- Declaration of Compliance
- Safety Compliances
- Electromagnetic Compatibility (EMC)
- Electromagnetic Compatibility Notice (USA)
- Electromagnetic Compatibility Notices (International)

Declaration of Compliance

We hereby certify that this product is in compliance with European Union EMC Directive 89/336/EEC, using standards EN55022 (Class A) and EN50082-1.

Safety Compliances

USA:	UL listed to 1950, 3rd Edition
Canada:	UL certified to CSA C22.2 No. 950-95 for Canada
Europe:	CE Mark 73/23/EEC

Electromagnetic Compatibility (EMC)

USA:	FCC 47 Class A CFR Parts 2 and 15, Tested Class A
Canada:	IC ICES-003 Class A
Europe:	EN55022, Class A EN50082-1 EN61000-4-2 ESD Susceptibility EN61000-4-3 Radiated Immunity EN61000-4-4 Electrical Fast Transient
International:	CISPR 22/93, Class A

Electromagnetic Compatibility Notice (USA)

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on; the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Any changes or modifications not expressly approved by the grantee of this device could void the user's authority to operate the equipment. The customer is responsible for ensuring compliance of the modified product.

Only peripherals (computer input/output devices, terminals, printers, etc.) that comply with FCC Class A limits may be attached to this computer product. Operation with noncompliant peripherals is likely to result in interference to radio and TV reception.

All cables used to connect to peripherals must be shielded and grounded. Operation with cables, connected to peripherals, that are not shielded and grounded may result in interference to radio and TV reception.

Note: A Class A device installed within a residential area is likely to cause harmful interference.

Electromagnetic Compatibility Notices (International)

When used near a radio or TV receiver, it may become the cause of radio interference.

Read the instructions for correct handling.

This equipment has been tested for radio frequency emissions and has been verified to meet CISPR 22 Class A.

Cet appareil numérique respecte les limites bruits radioélectriques applicables aux appareils numériques de Classe A prescrites dans la norme sur le matériel brouilleur: “Appareils Numériques”, NMB-003 édictée par le Ministre Canadien des Communications.


This digital apparatus does not exceed the Class A limits for radio noise emissions from digital apparatus set out in the interference-causing equipment standard entitled “Digital Apparatus”, ICES-003 of the Canadian Department of Communications.

Documentation of product compliance is on file with Solelectron, 2715 Banny Jones Avenue, West Columbia, SC 29170.

Safety Guidelines, Warnings, and Cautions


Refer to the following safety guidelines, warnings, and cautions when servicing your system.

Safety Guidelines and Warnings




There are no user-serviceable parts inside the power supply. Servicing should be done by technically qualified personnel only. There may be more than one power supply in this product.


Hazardous voltage, current, and energy levels are present inside the power supply and the power distribution backplane.



Do not attempt to modify or use the supplied AC power cord if it is not the exact type required.



The push-button power switch on the front panel of the system **DOES NOT** turn off the system AC power. To remove AC power from the system, you must unplug the AC power cord from the system or the wall outlet.



Hazardous electrical conditions may be present on power, telephone, and communication cables. Turn off the system and disconnect the AC power cord, telecommunications systems, networks, and modems attached to the system before opening it. Otherwise, personal injury or equipment damage can result.

SAFETY STEPS: Whenever you remove the side and/or front covers to access the Inside of the system, follow these steps:

Turn off all peripheral devices connected to the system.


Turn off the system by pressing the push-button power switch on the front of the system.

Unplug the AC power cord from the system or the wall outlet.

Label and disconnect all cables connected to I/O connectors or ports on the back of the system.

Provide some electrostatic discharge (ESD) protection by wearing an anti-static wrist strap attached to the chassis ground—any unpainted metal surface on the system—when handling components.

Do not operate the system with the side and/or front covers removed.




After you have completed the six SAFETY steps above, you can remove the front and/or side covers. To do this:

Unlock and remove the padlock from the back of the system if a padlock has been installed.

Remove and save all the screws from the covers.

Remove the covers.



For proper cooling and airflow, always reinstall the side and front covers before turning on the system. Operating the system without the covers in place can damage system parts. To install the covers:


Check first to make sure that you have not left any tools or loose parts inside the system.

Check that cables, expansion boards, and other components are properly installed.


Attach the covers to the chassis with the screws removed earlier, and tighten them firmly.

Insert and lock a padlock to the system cabinet to prevent unauthorized access inside the system.


Connect all external cables and the AC power cord to the system.



A processor and its heat sink may be hot if the system has been running. Also, there may be sharp pins and edges on some board and chassis parts. Contact should be made with care. Consider wearing protective gloves.



There is danger of an explosion if the battery is incorrectly replaced. Replace it only with the same or equivalent type recommended by the equipment manufacturer. Dispose of used batteries according to the manufacturer's instructions.



The system is designed to operate in a typical office environment. Choose a site that is:

Clean and free of airborne particles (other than normal room dust).

Well-ventilated and away from sources of heat, including direct sunlight.

Away from sources of vibration or physical shock.

Isolated from strong electromagnetic fields produced by electrical devices.

Provided with a properly grounded AC wall outlet.

Provided with sufficient space to access the power supply cords, because they serve as the system's main power disconnect.

In regions that are susceptible to electrical storms, we recommend you plug your system into a surge suppressor and disconnect telecommunication lines to your modem during an electrical storm.

Cautions

Electrostatic Discharge (ESD) and ESD Protection	ESD can damage disk drives, boards, and other components. This system can withstand normal levels of environmental ESD while you are hot-swapping SCSI hard disk drives and power supplies. However, we recommend that you perform all procedures in this manual only at an ESD workstation. If one is not available, you can provide some ESD protection by wearing an anti-static wrist strap attached to the chassis ground—any unpainted metal surface on the system—when handling components.
Handling Boards and Modules	Boards and modules can be extremely sensitive to ESD and always require careful handling. After removing a board or module from its protective wrapper or from the system, place the board or module component-side UP on a grounded, static-free surface. If you place the system board on a conductive surface, the battery leads may short out. If they do, the battery charge is drained, resulting in a loss of CMOS data. Do not slide any boards or modules across any surfaces.
Cooling and Airflow	Operating the system with the side and front covers removed can damage the components inside it. For proper cooling and airflow, always replace the covers before turning on the system.
Battery	There is danger of an explosion if the battery is incorrectly replaced. Replace it only with the same or equivalent type recommended by the equipment manufacturer. Dispose of the used battery according to the manufacturer's instructions.



531-0001444

04/99